

TOSHIBA

**DICOM CONFORMANCE STATEMENT
FOR
DIAGNOSTIC ULTRASOUND SYSTEM**

**MODEL SSA-580A *Nemio XGTM* V1.50
(DATA MANAGEMENT BOARD MODEL UIDM-580A)**

TOSHIBA MEDICAL SYSTEMS CORPORATION

© TOSHIBA MEDICAL SYSTEMS CORPORATION 2006
ALL RIGHTS RESERVED

Trademarks

Nemio XG is a trademark of Toshiba Medical Systems Corporation.
This document may include trademarks or registered trademarks of other companies.

IMPORTANT!

- (1) No part of this document may be copied or reprinted, in whole or in part, without written permission.
- (2) The contents of this document are subject to change without prior notice and without our legal obligation.

*

1. CONFORMANCE STATEMENT OVERVIEW

Table 1-1 provides an overview of the network services supported by *Nemio XGTM*.

**Table 1-1
NETWORK SERVICES**

SOP Classes	User of Service (SCU)	Provider of Service (SCP)
Transfer		
Secondary Capture Image Storage	Yes	Yes
Ultrasound Image Storage (retired)	Yes	Yes
Ultrasound Image Storage	Yes	Yes
Ultrasound Multi-frame Image Storage (retired)	Yes	Yes
Ultrasound Multi-frame Image Storage	Yes	Yes
Enhanced SR Storage	Yes	Yes
Storage Commitment		
Storage Commitment Push Model	Yes	No
Query/Retrieve		
Study Root Q/R Information Model – Find	Yes	No
Study Root Q/R Information Model – Move	Yes	No
Workflow Management		
Modality Worklist Information Model – Find	Yes	No
Modality Performed Procedure Step	Yes	No
Print Management		
Basic Grayscale Print Management	Yes	No
Basic Color Print Management	Yes	No

Table 1-2 provides an overview of the Media Storage Application Profiles supported by *Nemio XGTM*.

**Table 1-2
MEDIA SERVICES**

Media Storage Application Profile	Write Files (FSC)	Read Files (FSR)
Compact Disk – Recordable		
US Image CD	Yes	Yes
DVD Plus Recordable		
US Image DVD	Yes	Yes

2. TABLE OF CONTENTS

1. CONFORMANCE STATEMENT OVERVIEW	i
2. TABLE OF CONTENTS	a
3. INTRODUCTION	1
3.1 AUDIENCE	1
3.2 REMARKS	1
3.3 DEFINITIONS, TERMS AND ABBREVIATIONS.....	2
3.4 REFERENCES.....	2
4. NETWORKING	3
4.1 IMPLEMENTATION MODEL.....	3
4.1.1 Application Data Flow	3
4.1.2 Functional Definition of AEs.....	5
4.1.3 Sequencing of Real-World Activities.....	6
4.2 AE SPECIFICATIONS	8
4.2.1 Verification SCU AE Specification	8
4.2.2 Verification SCP AE Specification	11
4.2.3 Storage SCU AE Specification	14
4.2.4 Storage Commitment SCU AE Specification.....	18
4.2.5 MWM SCU AE Specification.....	23
4.2.6 MPPS SCU AE Specification.....	29
4.2.7 Q/R SCU AE Specification.....	35
4.2.8 Storage SCP AE Specification.....	41
4.2.9 Print SCU AE Specification.....	45
4.3 NETWORK INTERFACES	55
4.3.1 Physical Network Interface	55
4.3.2 Additional Protocols	55
4.4 CONFIGURATION	56
4.4.1 AE Title/Presentation Address Mapping.....	56
4.4.2 Parameters	57
5. MEDIA INTERCHANGE	58
5.1 IMPLEMENTATION MODEL.....	58
5.1.1 Application Data Flow	58
5.1.2 Functional Definition of AEs.....	58
5.1.3 Sequencing of Real-World Activities.....	59
5.1.4 File Meta Information for Implementation Class and Version.....	59
5.2 AE SPECIFICATIONS	60
5.2.1 Offline-Media AE Specification	60
5.3 AUGMENTED AND PRIVATE APPLICATION PROFILES.....	61
5.3.1 Augmented Application Profiles.....	61
5.3.2 Private Application Profiles	61
5.4 MEDIA CONFIGURATION	61

6.	SUPPORT OF CHARACTER SETS.....	62
7.	SECURTIY.....	63
8.	ANNEXES	64
8.1	IOD CONTENTS	64
8.1.1	Created SOP Instances	64
8.1.2	Usage of Attributes from received IOD's	201
8.1.3	Attribute Mapping.....	201
8.1.4	Coerced/Modified Fields	202
8.2	DATA DICTIONARY OF PRIVATE ATTRIBUTES	202
8.3	CONTROLLED TERMINOLOGY AND TEMPLATES	202
8.4	GRAYSCALE IMAGE CONSISTENCY.....	202
8.5	STANDARD EXTENDED/SPECIALIZED/PRIVATE SOP CLASSES.....	202
8.6	PRIVATE TRANSFER SYNTAXES	202

*

3. INTRODUCTION

3.1 AUDIENCE

This document is intended for hospital staff, health system integrators, software designers or implementers. It is assumed that the reader has a working understanding of DICOM.

3.2 REMARKS

DICOM, by itself, does not guarantee interoperability. However, the Conformance Statement facilitates a first-level validation for interoperability between different applications supporting the same DICOM functionality.

This Conformance Statement is not intended to replace validation with other DICOM equipment to ensure proper exchange of information intended.

The scope of this Conformance Statement is to facilitate communication with Toshiba Medical Systems and other vendors' Medical equipment. The Conformance Statement should be read and understood in conjunction with the DICOM Standard [DICOM]. However, by itself it is not guaranteed to ensure the desired interoperability and a successful interconnectivity.

The user should be aware of the following important issues:

- The comparison of different conformance statements is the first step towards assessing interconnectivity between Toshiba Medical Systems and non-Toshiba Medical Systems equipment.
- Test procedures should be defined to validate the desired level of connectivity.
- The DICOM standard will evolve to meet the users' future requirements. Toshiba Medical Systems is actively involved in developing the standard further and therefore reserves the right to make changes to its products or to discontinue its delivery.

3.3 DEFINITIONS, TERMS AND ABBREVIATIONS

Definitions, terms and abbreviations used in this document are defined within the different parts of the DICOM standard.

Abbreviations and terms are as follows:

AE	Application Entity
CD-R	Compact Disk Recordable
DIMSE	DICOM Message Service Element
DVD	A trademark of the DVD forum that is not an abbreviation
DVD+R	DVD Plus Recordable
FSC	File-Set Creator
FSR	File-Set Reader
IE	Information Entity
IOD	Information Object Definition
ISO	International Standard Organization
MPPS	Modality Performed Procedure Step
MSPS	Modality Scheduled Procedure Step
MWM	Modality Worklist Management
PDU	Protocol Data Unit
SCU	Service Class User (DICOM client)
SCP	Service Class Provider (DICOM server)
SOP	Service-Object Pair
UID	Unique Identifier

3.4 REFERENCES

[DICOM] Digital Imaging and Communications in Medicine (DICOM), NEMA PS 3.1-3.18, 2006

4. NETWORKING

4.1 IMPLEMENTATION MODEL

4.1.1 Application Data Flow




Figure 4.1-1
APPLICATION DATA FLOW DIAGRAM

- The Verification SCU AE issues a C-ECHO to verify a DICOM connection to a remote AE. It is associated with the local real-world activity “Verify Connectivity”. “Verify Connectivity” is performed via the Service Tool.
- The Verification SCP AE responds successfully to C-ECHO requests from a remote AE. It is associated with the local real-world activity “Respond to Verification Request”
- The Storage SCU AE sends images to a remote AE. It is associated with the local real-world activity “Send Images”. “Send Images” is performed upon user request for specific images selected. If the remote AE is configured as a Storage Commitment SCP AE, the Storage SCU AE will send a storage commitment request to the Storage Commitment SCU AE.
- Receiving the storage commitment request from the Storage SCU AE, the Storage Commitment SCU AE will request Storage Commitment and if a commitment is successfully obtained will record this information in the local database.
- The MWM SCU AE receives worklist information from a remote AE. It is associated with the local real-world activity “Update Worklist”. When the “Update Worklist” is performed the MWM SCU AE queries a remote AE for worklist items and provides the set of worklist items matching the query request. “Update Worklist” is performed as a result of an operator request.
- The MPPS SCU AE sends MPPS information to a remote AE. It is associated with the local real-world activity “Acquire Images”. When the “Acquire Images” is performed the MPPS SCU AE creates and updates Modality Performed Procedure Step instances managed by a remote AE. Acquisition of images will result in automated creation of an MPPS Instance. Completion of the MPPS is performed as the result of an operator action.
- The Q/R SCU AE queries a remote AE for lists of studies and retrieves selected studies. It is associated with the local real-world activity “Query and Retrieve Images”.
- The Storage SCP AE receives incoming images. It is associated with the local real-world activity “Store Images to the Local File System”. “Store Images to the Local File System” stores the received images to the local file system.
- The Print SCU AE prints images on a remote AE (Printer). It is associated with the local real-world activity “Send Images & Print Management Information”. “Send Images & Print Management Information” creates a print-job within the print queue containing one or more virtual film sheets composed from images selected by the user.

4.1.2 Functional Definition of AEs

4.1.2.1 Functional Definition of Verification SCU AE

The Verification SCU AE issues a C-ECHO to verify a DICOM connection to a remote AE. It is performed via the Service Tool.

4.1.2.2 Functional Definition of Verification SCP AE

The Verification SCP AE responds successfully to C-ECHO requests from a remote AE.

4.1.2.3 Functional Definition of Storage SCU AE

The existence of a send-job queue entry with associated network destination will activate the Storage SCU AE. An association request is sent to the destination AE and upon successful negotiation of a Presentation Context the image transfer is started. If the image transfer fails, the Storage SCU AE will retry this send-job automatically. If the remote AE is configured as a Storage Commitment SCP AE, the Storage SCU AE will send a storage commitment request to the Storage Commitment SCU AE.

4.1.2.4 Functional Definition of Storage Commitment SCU AE

Receiving the storage commitment request from the Storage SCU AE, the Storage Commitment SCU AE will request Storage Commitment and if a commitment is successfully obtained will record this information in the local database.

4.1.2.5 Functional Definition of MWM SCU AE

The MWM SCU AE attempts to download a worklist from a remote node. If the MWM SCU AE establishes an association to a remote AE, it will transfer patient's information and worklist items via the open association. The results will be displayed in a separate list. The patient's information will be used for the patient registration.

4.1.2.6 Functional Definition of MPPS SCU AE

The MPPS SCU AE performs the creation of an MPPS Instance automatically when the user selects and starts a worklist item. Further updates on the MPPS data can be performed automatically.

4.1.2.7 Functional Definition of Q/R SCU AE

The Q/R SCU AE is activated when the user selects a remote node to query and enters some key information, Patient's Name, Patient ID and/or Accession Number. The user can select studies to be retrieved. The images will be received at the Storage SCP AE.


4.1.2.8 Functional Definition of Storage SCP AE

The Storage SCP AE waits for another application to connect at the presentation address configured for its AE Title. The Storage SCP AE will accept associations with Presentation Contexts for SOP Classes of the Verification and Storage Service Classes. Any images received on such Presentation Contexts will be stored to the local file system.

4.1.2.9 Functional Definition of Print SCU AE

The existence of a print-job in the print queue will activate the Print SCU AE. An association is established with the printer and the printer's status determined. If the printer is operating normally, the film sheets described within the print-job will be printed. If the printer is not operating normally, this print-job can be canceled or restarted by the user operations.

4.1.3 Sequencing of Real-World Activities



**Figure 4.1-2
SEQUENCING CONSTRAINTS**

Under typical scheduled workflow conditions the sequencing constraints illustrated in Figure 4.1-2 apply:

1. Query Worklist
2. Receive Worklist of Modality Scheduled Procedure Steps (MSPS)
3. Select Workitem (MSPS) from Worklist
4. Start Acquisition and Create MPPS
5. Acquire Images
6. Complete Acquisition and Finalize MPPS
7. Store Acquired Images
8. Commit Acquired Images
9. Query/Retrieve Images
10. Receive Images
11. Print Images

Other workflow situations (e.g. unscheduled procedure steps) will have other sequencing constraints. Some activities may be omitted according to situations.

4.2 AE SPECIFICATIONS

4.2.1 Verification SCU AE Specification

4.2.1.1 SOP Classes

The Verification SCU AE provides Standard Conformance to the following SOP Classes:

**Table 4.2-1
SOP CLASSES FOR THE VERIFICATION SCU AE**

SOP Class Name	SOP Class UID	SCU	SCP
Verification	1.2.840.10008.1.1	Yes	No

4.2.1.2 Association Policies

4.2.1.2.1 General

The DICOM standard application context name for DICOM 3.0 is always proposed:

**Table 4.2-2
DICOM APPLICATION CONTEXT FOR THE VERIFICATION SCU AE**

Application Context Name	1.2.840.10008.3.1.1.1
--------------------------	-----------------------

4.2.1.2.2 Number of Associations

The Verification SCU AE initiates one association at a time.

**Table 4.2-3
NUMBER OF ASSOCIATIONS INITIATED FOR THE VERIFICATION SCU AE**

Maximum number of simultaneous associations	1
---	---

4.2.1.2.3 Asynchronous Nature

The Verification SCU AE does not support asynchronous communication (multiple outstanding transactions over a single association).

**Table 4.2-4
ASYNCHRONOUS NATURE FOR THE VERIFICATION SCU AE**

Maximum number of outstanding asynchronous transactions	1
---	---

4.2.1.2.4 Implementation Identifying Information

The implementation information for the Verification SCU AE is:

**Table 4.2-5
DICOM IMPLEMENTATION CLASS AND VERSION FOR THE VERIFICATION SCU AE**


Implementation Class UID	2.16.124.113531.1.1
Implementation Version Name	Cedara RMA v3.0

4.2.1.3 Association Initiation Policy

4.2.1.3.1 Activity – Verify Connectivity

4.2.1.3.1.1 Description and Sequencing of Activities

The Verification SCU AE attempts to initiate a new association in order to issue a verification request (C-ECHO) if needed.



**Figure 4.2-1
SEQUENCING OF ACTIVITY – VERIFY CONNECTIVITY**

A possible sequence of interactions between the Verification SCU AE and an Image Server (e.g. a storage or archive device supporting the Verification SOP Classes as an SCP) is illustrated in the Figure above:

1. The Verification SCU AE opens an association with the Image Server.
2. The Verification SCU AE issues a verification request (C-ECHO) and the Image Server replies with a C-ECHO response (status success).
3. The Verification SCU AE closes the association with the Image Server.

4.2.1.3.1.2 Proposed Presentation Contexts

The Verification SCU AE will propose the Presentation Contexts shown in the following table:

**Table 4.2-6
PROPOSED PRESENTATION CONTEXTS FOR ACTIVITY VERIFY CONNECTIVITY**

Presentation Context Table					
Abstract Syntax		Transfer Syntax		Role	Ext. Neg.
Name	UID	Name List	UID List		
Verification	1.2.840.10008.1.1	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None

4.2.1.3.1.3 SOP Specific Conformance for Verification SOP Class

The Verification SCU AE provides standard conformance to the Verification Service Class as an SCU.

The behavior of Verification SCU AE when encountering status codes in a C-ECHO response is summarized in the table below:

**Table 4.2-7
VERIFICATION RESPONSE STATUS HANDLING BEHAVIOR**

Service Status	Further Meaning	Status Code	Behavior
Success	Success	0000	The Verification SCU AE judges the remote AE is present and active on the network.

The behavior of Verification SCU AE during communication failure is summarized in the table below:

**Table 4.2-8
VERIFICATION COMMUNICATION FAILURE BEHAVIOR**

Exception	Behavior
Timeout	The association is aborted and the send job is marked as failed. The reason is logged and the job failure is reported to the user via the job control application.
Association aborted by the SCP or network layers	The send job is marked as failed. The reason is logged and the job failure is reported to the user via the job control application.

4.2.2 Verification SCP AE Specification

4.2.2.1 SOP Classes

The Verification SCP AE provides Standard Conformance to the following SOP Classes:

**Table 4.2-9
SOP CLASSES FOR THE VERIFICATION SCP AE**

SOP Class Name	SOP Class UID	SCU	SCP
Verification	1.2.840.10008.1.1	No	Yes

4.2.2.2 Association Policies

4.2.2.2.1 General

The DICOM standard application context name for DICOM 3.0 is always proposed:

**Table 4.2-10
DICOM APPLICATION CONTEXT FOR THE VERIFICATION SCP AE**

Application Context Name	1.2.840.10008.3.1.1.1
--------------------------	-----------------------

4.2.2.2.2 Number of Associations

The Verification SCP AE supports one association at a time.

**Table 4.2-11
NUMBER OF ASSOCIATIONS ACCEPTED FOR THE VERIFICATION SCP AE**

Maximum number of simultaneous associations	1
---	---

4.2.2.2.3 Asynchronous Nature

The Verification SCP AE does not support asynchronous communication (multiple outstanding transactions over a single association).

**Table 4.2-12
ASYNCHRONOUS NATURE FOR THE VERIFICATION SCP AE**

Maximum number of outstanding asynchronous transactions	1
---	---

4.2.2.2.4 Implementation Identifying Information

The implementation information for the Verification SCP AE is:

**Table 4.2-13
DICOM IMPLEMENTATION CLASS AND VERSION FOR THE VERIFICATION SCP AE**

Implementation Class UID	2.16.124.113531.1.1
Implementation Version Name	Cedara RMA v3.0

4.2.2.3 Association Initiation Policy


The Verification SCP AE does not initiate associations.

4.2.2.4 Association Acceptance Policy

4.2.2.4.1 Activity – Respond to Verification Request

4.2.2.4.1.1 Description and Sequencing of Activities

When the Verification SCP AE accepts an association, it will respond to a verification request (C-ECHO).



**Figure 4.2-2
SEQUENCING OF ACTIVITY – RESPOND TO VERIFICATION REQUEST**

A possible sequence of interactions between the Verification SCP AE and an Image Server (e.g. a storage or archive device supporting the Verification SOP Classes as an SCU) is illustrated in the Figure above:

1. The Image Server opens an association with the Verification SCP AE.
2. The Image Server issues a verification request (C-ECHO) and the Verification SCP AE replies with a C-ECHO response (status success).
3. The Image Server closes the association with the Verification SCP AE.

The Verification SCP AE does not care about a called/calling AE title contained in association requests.

4.2.2.4.1.2 Accepted Presentation Contexts

The Verification SCP AE will accept Presentation Contexts shown in the table below.

Table 4.2-14

PROPOSED PRESENTATION CONTEXTS FOR ACTIVITY RESPOND TO VERIFICATION REQUEST

Presentation Context Table					
Abstract Syntax		Transfer Syntax		Role	Ext. Neg.
Name	UID	Name List	UID List		
Verification	1.2.840.10008.1.1	Implicit VR LittleEndian	1.2.840.10008.1.2	SCP	None

4.2.2.4.1.3 SOP Specific Conformance for Verification SOP Class

The Verification SCP AE provides standard conformance to the Verification Service Class as an SCP.

4.2.3 Storage SCU AE Specification

4.2.3.1 SOP Classes

The Storage SCU AE provides Standard Conformance to the following SOP Classes:

**Table 4.2-15
SOP CLASSES FOR THE STORAGE SCU AE**

SOP Class Name	SOP Class UID	SCU	SCP
Secondary Capture Image Storage	1.2.840.10008.5.1.4.1.1.7	Yes	No
Ultrasound Image Storage (retired)	1.2.840.10008.5.1.4.1.1.6		
Ultrasound Image Storage	1.2.840.10008.5.1.4.1.1.6.1		
Ultrasound Multi-frame Image Storage (retired)	1.2.840.10008.5.1.4.1.1.3		
Ultrasound Multi-frame Image Storage	1.2.840.10008.5.1.4.1.1.3.1		
Enhanced SR Storage	1.2.840.10008.5.1.4.1.1.88.22		

4.2.3.2 Association Policies

4.2.3.2.1 General

The DICOM standard application context name for DICOM 3.0 is always proposed:

**Table 4.2-16
DICOM APPLICATION CONTEXT FOR THE STORAGE SCU AE**

Application Context Name	1.2.840.10008.3.1.1.1
--------------------------	-----------------------

4.2.3.2.2 Number of Associations

The Storage SCU AE initiates one association at a time. Until the active job is completed or failed, the other remains pending.

**Table 4.2-17
NUMBER OF ASSOCIATIONS INITIATED FOR THE STORAGE SCU AE**

Maximum number of simultaneous associations	1
---	---

4.2.3.2.3 Asynchronous Nature

The Storage SCU AE does not support asynchronous communication (multiple outstanding transactions over a single association).

**Table 4.2-18
ASYNCHRONOUS NATURE FOR THE STORAGE SCU AE**

Maximum number of outstanding asynchronous transactions	1
---	---

4.2.3.2.4 Implementation Identifying Information

The implementation information for the Storage SCU AE is:

**Table 4.2-19
DICOM IMPLEMENTATION CLASS AND VERSION FOR THE STORAGE SCU AE**


Implementation Class UID	2.16.124.113531.1.1
Implementation Version Name	Cedara RMA v3.0

4.2.3.3 Association Initiation Policy

4.2.3.3.1 Activity – Send Images

4.2.3.3.1.1 Description and Sequencing of Activities

The Storage SCU AE attempts to initiate a new association in order to issue a storage request (C-STORE). If the job contains multiple images then multiple C-STORE requests will be issued over the same association. If the image transfer fails, the Storage SCU AE will retry this send-job automatically.



**Figure 4.2-3
SEQUENCING OF ACTIVITY – SEND IMAGES**

A possible sequence of interactions between the Storage SCU AE and an Image Server (e.g. a storage or archive device supporting the Storage SOP Classes as an SCP) is illustrated in the Figure above:

1. The Storage SCU AE opens an association with the Image Server.
2. Acquired images are transmitted to the Image Server using a storage request (C-STORE) and the Image Server replies with a C-STORE response (status success).
3. The Storage SCU AE closes the association with the Image Server.

4.2.3.3.1.2 Proposed Presentation Contexts

The Storage SCU AE will propose the Presentation Contexts shown in the following table:

**Table 4.2-20
PROPOSED PRESENTATION CONTEXTS FOR ACTIVITY SEND IMAGES**

Presentation Context Table					
Abstract Syntax		Transfer Syntax		Role	Ext. Neg.
Name	UID	Name List	UID List		
Secondary Capture Image Storage	1.2.840.10008.5.1.4.1.1.7	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None
		Explicit VR LittleEndian	1.2.840.10008.1.2.1		
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50		
		RLE Lossless	1.2.840.10008.1.2.5		
Ultrasound Image Storage (retired)	1.2.840.10008.5.1.4.1.1.6	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None
		Explicit VR LittleEndian	1.2.840.10008.1.2.1		
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50		
		RLE Lossless	1.2.840.10008.1.2.5		
Ultrasound Image Storage	1.2.840.10008.5.1.4.1.1.6.1	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None
		Explicit VR LittleEndian	1.2.840.10008.1.2.1		
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50		
		RLE Lossless	1.2.840.10008.1.2.5		
Ultrasound Multi-frame Image Storage (retired)	1.2.840.10008.5.1.4.1.1.3	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None
		Explicit VR LittleEndian	1.2.840.10008.1.2.1		
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50		
		RLE Lossless	1.2.840.10008.1.2.5		
Ultrasound Multi-frame Image Storage	1.2.840.10008.5.1.4.1.1.3.1	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None
		Explicit VR LittleEndian	1.2.840.10008.1.2.1		
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50		
		RLE Lossless	1.2.840.10008.1.2.5		
Enhanced SR Storage	1.2.840.10008.5.1.4.1.1.88.22	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None
		Explicit VR LittleEndian	1.2.840.10008.1.2.1		

4.2.3.3.1.3 SOP Specific Conformance for Storage SOP Classes

The Storage SCU AE provides standard conformance to the Storage Service Class as an SCU.

The behavior of Storage SCU AE when encountering status codes in a C-STORE response is summarized in the table below:

**Table 4.2-21
STORAGE C-STORE RESPONSE STATUS HANDLING BEHAVIOR**

Service Status	Further Meaning	Status Code	Behavior
Success	Success	0000	The SCP has successfully stored the SOP Instance. If all SOP Instances in a send job have status success then the job is marked as complete.
*	*	Any other status code	The association is aborted and the send job is marked as failed. The status meaning is logged and the job failure is reported to the user via the job control application.

The behavior of Storage SCU AE during communication failure is summarized in the table below:

**Table 4.2-22
STORAGE COMMUNICATION FAILURE BEHAVIOR**

Exception	Behavior
Timeout	The association is aborted and the send job is marked as failed. The reason is logged and the job failure is reported to the user via the job control application.
Association aborted by the SCP or network layers	The send job is marked as failed. The reason is logged and the job failure is reported to the user via the job control application.

If the image transfer fails, the Storage SCU AE will retry this send-job automatically.

The contents of Image Storage SOP Instances created by the Storage SCU AE conform to the DICOM Image IOD definitions and are described in section 8.1.

4.2.4 Storage Commitment SCU AE Specification

4.2.4.1 SOP Classes

The Storage Commitment SCU AE provides Standard Conformance to the following SOP Classes:

**Table 4.2-23
SOP CLASSES FOR THE STORAGE COMMITMENT SCU AE**

SOP Class Name	SOP Class UID	SCU	SCP
Storage Commitment Push Model	1.2.840.10008.1.20.1	Yes	No

4.2.4.2 Association Policies

4.2.4.2.1 General

The DICOM standard application context name for DICOM 3.0 is always proposed:

**Table 4.2-24
DICOM APPLICATION CONTEXT FOR THE STORAGE COMMITMENT SCU AE**

Application Context Name	1.2.840.10008.3.1.1.1
--------------------------	-----------------------

4.2.4.2.2 Number of Associations

The Storage Commitment SCU AE initiates one association at a time.

**Table 4.2-25
NUMBER OF ASSOCIATIONS INITIATED FOR THE STORAGE COMMITMENT SCU AE**

Maximum number of simultaneous associations	1
---	---

The Storage Commitment SCU AE accepts one association at a time to receive an N-EVENT-REPORT notification for the Storage Commitment Push Model SOP Class.

**Table 4.2-26
NUMBER OF ASSOCIATIONS ACCEPTED FOR THE STORAGE COMMITMENT SCU AE**

Maximum number of simultaneous associations	1
---	---

4.2.4.2.3 Asynchronous Nature

The Storage Commitment SCU AE does not support asynchronous communication (multiple outstanding transactions over a single association).

**Table 4.2-27
ASYNCHRONOUS NATURE FOR THE STORAGE COMMITMENT SCU AE**

Maximum number of outstanding asynchronous transactions	1
---	---

4.2.4.2.4 Implementation Identifying Information

The implementation information for the Storage Commitment SCU AE is:

**Table 4.2-28
DICOM IMPLEMENTATION CLASS AND VERSION FOR THE STORAGE COMMITMENT SCU AE**


Implementation Class UID	2.16.124.113531.1.1
Implementation Version Name	Cedara RMA v3.0

4.2.4.3 Association Initiation Policy

4.2.4.3.1 Activity – Commit Sent Images

4.2.4.3.1.1 Description and Sequencing of Activities

If the remote AE is configured as a Storage Commitment SCP AE, the Storage Commitment SCU AE will, after all images have been sent, transmit a single storage commitment request (N-ACTION). Upon receiving the N-ACTION response the Storage Commitment SCU AE will release the association. The notification of storage commitment (N-EVENT-REPORT) will be received over a separate association.



**Figure 4.2-4
SEQUENCING OF ACTIVITY – COMMIT SENT IMAGES**

A possible sequence of interactions between the Storage Commitment SCU AE and an Image Server (e.g. a storage or archive device supporting the Storage Commitment SOP Classes as an SCP) is illustrated in the Figure above:

1. The Storage Commitment SCU AE opens an association with the Image Server.
2. A storage commitment request (N-ACTION) is transmitted to the Image Server to obtain storage commitment of previously transmitted images. The Image Server replies with an N-ACTION response indicating the request has been received and is being processed.
3. The Storage Commitment SCU AE closes the association with the Image Server.

Note: The N-EVENT-REPORT will be sent over a separate association initiated by the Image Server.
(see Section 4.2.4.4.1)

4.2.4.3.1.2 Proposed Presentation Contexts

The Storage Commitment SCU AE will propose the Presentation Contexts shown in the following table:

**Table 4.2-29
PROPOSED PRESENTATION CONTEXTS FOR ACTIVITY COMMIT SENT IMAGES**

Presentation Context Table					
Abstract Syntax		Transfer Syntax		Role	Ext. Neg.
Name	UID	Name List	UID List		
Storage Commitment Push Model	1.2.840.10008.1.20.1	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None

A Presentation Context for the Storage Commitment Push Model will only be proposed if the remote AE is configured as a Storage Commitment SCP AE.

4.2.4.3.1.3 SOP Specific Conformance for Storage Commitment SOP Class

4.2.4.3.1.3.1 Storage Commitment Operations (N-ACTION)

The Storage Commitment SCU AE provides standard conformance to the Storage Commitment Service Class as an SCU.

The Storage Commitment SCU AE will request storage commitment for instances of the Storage SOP Classes if the remote AE is configured as a Storage Commitment SCP AE and a presentation context for the Storage Commitment Push Model has been accepted.

The behavior of Storage SCU Commitment AE when encountering status codes in a N-ACTION response is summarized in the table below:

**Table 4.2-30
STORAGE COMMITMENT N-ACTION RESPONSE STATUS HANDLING BEHAVIOR**

Service Status	Further Meaning	Status Code	Behavior
Success	Success	0000	The request for storage commitment is considered successfully sent. A timer is started which will expire if no N-EVENT-REPORT for the Transaction UID is received within a configurable timeout period.
*	*	Any other status code	The association is aborted and the request for storage commitment is marked as failed.

The behavior of Storage Commitment AE during communication failure is summarized in the table below:

**Table 4.2-31
STORAGE COMMITMENT COMMUNICATION FAILURE BEHAVIOR**


Exception	Behavior
Timeout	The association is aborted and the send job is marked as failed. The reason is logged and the job failure is reported to the user via the job control application.
Association aborted by the SCP or network layers	The send job is marked as failed. The reason is logged and the job failure is reported to the user via the job control application.

4.2.4.4 Association Acceptance Policy

4.2.4.4.1 Activity – Receive Storage Commitment Response

4.2.4.4.1.1 Description and Sequencing of Activities

The Storage Commitment SCU AE will accept associations in order to receive responses to a storage commitment request.



**Figure 4.2-5
SEQUENCING OF ACTIVITY - RECEIVE STORAGE COMMITMENT RESPONSE**

A possible sequence of interactions between the Storage Commitment SCU AE and an Image Server (e.g. a storage or archive device supporting Storage Commitment SOP Classes as an SCP) is illustrated in the Figure above:

1. The Image Server opens an association with the Storage Commitment SCU AE.
2. The Image Server sends an N-EVENT-REPORT request notifying the Storage SCU AE of the status of a previous storage commitment request. The Storage SCU AE replies with an N-EVENT-REPORT response confirming receipt.
3. The Image Server closes the association with the Storage Commitment SCU AE.

The Storage Commitment SCU AE does not care about a called/calling AE title contained in association requests.

4.2.4.4.1.2 Accepted Presentation Contexts

The Storage Commitment SCU AE will accept Presentation Contexts shown in the table below.

**Table 4.2-32
ACCEPTABLE PRESENTATION CONTEXTS FOR
ACTIVITY RECEIVE STORAGE COMMITMENT RESPONSE**

Presentation Context Table					
Abstract Syntax		Transfer Syntax		Role	Ext. Neg.
Name	UID	Name List	UID List		
Storage Commitment Push Model	1.2.840.10008.1.20.1	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None

4.2.4.4.1.3 SOP Specific Conformance for Storage Commitment SOP Class

4.2.4.4.1.3.1 Storage Commitment Notifications (N-EVENT-REPORT)

The Storage Commitment SCU AE provides standard conformance to the Storage Commitment Service Class as an SCU.

The behavior of Storage Commitment SCU AE when receiving Event Types within the N-EVENT-REPORT is summarized in the table below.

**Table 4.2-33
STORAGE COMMITMENT N-EVENT-REPORT BEHAVIOUR**

Event Type Name	Event Type ID	Behavior
Storage Commitment Request Successful	1	The Storage Commitment SCU AE permits the operator(s) to delete the Referenced SOP Instances under Referenced SOP Sequence (0018,1199), or deletes the Instances from the local database automatically.
Storage Commitment Request Complete – Failures Exist	2	The Storage Commitment SCU AE requests the Storage SCU AE to send the Referenced SOP Instances under Failed SOP Sequence (0018,1198).

The reasons for returning specific status codes in a N-EVENT-REPORT response are summarized in the table below.

**Table 4.2-34
STORAGE COMMITMENT N-EVENT-REPORT RESPONSE STATUS REASONS**

Service Status	Further Meaning	Status Code	Reasons
Success	Success	0000	The storage commitment result has been successfully received.
Failure	Processing Failure	0110H	An internal error occurred during processing of the N-EVENT-REPORT. A short description of the error will be returned in Error Comment (0000,0902).

4.2.5 MWM SCU AE Specification

4.2.5.1 SOP Classes

The MWM SCU AE provides Standard Conformance to the following SOP Classes:

**Table 4.2-35
SOP CLASSES FOR THE MWM SCU AE**

SOP Class Name	SOP Class UID	SCU	SCP
Modality Worklist Information Model – FIND	1.2.840.10008.5.1.4.31	Yes	No

4.2.5.2 Association Policies

4.2.5.2.1 General

The DICOM standard application context name for DICOM 3.0 is always proposed:

**Table 4.2-36
DICOM APPLICATION CONTEXT FOR THE MWM SCU AE**

Application Context Name	1.2.840.10008.3.1.1.1
--------------------------	-----------------------

4.2.5.2.2 Number of Associations

The MWM SCU AE initiates one association at a time for a worklist request.

**Table 4.2-37
NUMBER OF ASSOCIATIONS INITIATED FOR THE MWM SCU AE**

Maximum number of simultaneous associations	1
---	---

4.2.5.2.3 Asynchronous Nature

The MWM SCU AE does not support asynchronous communication (multiple outstanding transactions over a single association).

**Table 4.2-38
ASYNCHRONOUS NATURE FOR THE MWM SCU AE**

Maximum number of outstanding asynchronous transactions	1
---	---

4.2.5.2.4 Implementation Identifying Information

The implementation information for this Application Entity is:

**Table 4.2-39
DICOM IMPLEMENTATION CLASS AND VERSION FOR THE MWM SCU AE**

Implementation Class UID	2.16.124.113531.1.1
Implementation Version Name	Cedara RMA v3.0

4.2.5.3 Association Initiation Policy


4.2.5.3.1 Activity – Update Worklist

4.2.5.3.1.1 Description and Sequencing of Activities

The request for an “Update Worklist” is initiated by user interaction, i.e. pressing the buttons “Retrieve Worklist”.

Upon initiation of the request, the MWM SCU AE will build an Identifier for the C-FIND request, will initiate an association to send the request and will wait for worklist responses. After retrieval of all responses, the MWM SCU AE will access the local database to add or update patient demographic data. The results will be displayed in a separate list.

The MWM SCU AE will initiate an association in order to issue a C-FIND request according to the Modality Worklist Information Model.



**Figure 4.2-6
SEQUENCING OF ACTIVITY – UPDATE WORKLIST**

A possible sequence of interactions between the MWM SCU AE and a Department Scheduler (e.g. a device such as a RIS or HIS which supports the Modality Worklist SOP Class as an SCP) is illustrated in the Figure above:

1. The MWM SCU AE opens an association with the Department Scheduler
2. The MWM SCU AE sends a C-FIND request to the Department Scheduler containing the Worklist Query attributes.
3. The Department Scheduler returns a C-FIND response containing the requested attributes of the first matching worklist item.
4. The Department Scheduler returns another C-FIND response containing the requested attributes of the second matching worklist item.
5. The Department Scheduler returns another C-FIND response with status Success indicating that no further matching worklist items exist. This example assumes that only 2 worklist items match the Worklist Query.
6. The MWM SCU AE closes the association with the Department Scheduler.
7. The user selects a worklist item from the Worklist and prepares to acquire new images.

4.2.5.3.1.2 Proposed Presentation Contexts

The MWM SCU AE will propose Presentation Contexts shown in the following table:

**Table 4.2-40
PROPOSED PRESENTATION CONTEXTS FOR ACTIVITY UPDATE WORKLIST**

Presentation Context Table					
Abstract Syntax		Transfer Syntax		Role	Ext. Neg.
Name	UID	Name List	UID List		
Modality Worklist Information Model – FIND	1.2.840.10008.5.1.4.31	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None

4.2.5.3.1.3 SOP Specific Conformance for Modality Worklist SOP Class

The MWM SCU AE provides standard conformance to the Modality Worklist SOP Class as an SCU.

The behavior of the MWM SCU when encountering status codes in a Modality Worklist C-FIND response is summarized in the table below.

**Table 4.2-41
MODALITY WORKLIST C-FIND RESPONSE STATUS HANDLING BEHAVIOR**

Service Status	Further Meaning	Status Code	Behavior
Success	Matching is complete	0000	The SCP has completed the matches. Worklist items are available for display or further processing.
*	*	Any other status code	The association is aborted using A-ABORT and the status meaning is logged.

The behavior of the MWM SCU AE during communication failure is summarized in the table below.

**Table 4.2-42
MODALITY WORKLIST COMMUNICATION FAILURE BEHAVIOR**

Exception	Behavior
Timeout	The association is aborted using A-ABORT and the reason is logged.
Association aborted by the SCP or network layers	The reason is logged.

Acquired images will always use the Study Instance UID specified for the Scheduled Procedure Step (if available). If an acquisition is unscheduled, a Study Instance UID will be generated locally.

The table below provides a description of the MWM SCU AE Worklist Request Identifier and specifies the attributes that are copied into the images. Unexpected attributes returned in a C-FIND response are ignored.

**Table 4.2-43
WORKLIST REQUEST IDENTIFIER**

Module Name Attribute Name	Tag	VR	M	R	D	IOD
SOP Common Module						
Specific Character Set	(0008,0005)	CS				
Scheduled Procedure Step Module						
Scheduled Procedure Step Sequence	(0040,0100)	SQ		x		
>Modality	(0008,0060)	CS	S	x		x
>Requested Contrast Agent	(0032,1070)	LO				
>Scheduled Station AE Title	(0040,0001)	AE	S	x		
>Scheduled Procedure Step Start Date	(0040,0002)	DA	R	x	x	
>Scheduled Procedure Step Start Time	(0040,0003)	TM		x	x	
>Scheduled Procedure Step End Date	(0040,0004)	DA				
>Scheduled Procedure Step End Time	(0040,0005)	TM				
>Scheduled Performing Physician's Name	(0040,0006)	PN		x		
>Scheduled Procedure Step Description	(0040,0007)	SH		x		x
>Scheduled Protocol Code Sequence	(0040,0008)	SQ		x	x	
>Scheduled Procedure Step ID	(0040,0009)	SH		x		x
>Scheduled Station Name	(0040,0010)	LO		x		
>Scheduled Procedure Step Location	(0040,0011)	SH		x		
>Pre-Medication	(0040,0012)	CS		x		
>Scheduled Procedure Step Status	(0040,0020)	LO				
>Comments on Scheduled Procedure Step	(0040,0400)	LT		x		
Requested Procedure Module						
Referenced Study Sequence	(0008,1110)	SQ		x		x
Study Instance UID	(0020,000D)	UI		x		x
Requested Procedure Description	(0032,1060)	LO		x	x	
Requested Procedure Code Sequence	(0032,1064)	SQ		x	x	
Requested Procedure ID	(0040,1001)	SH	S	x	x	x
Reason for the Requested Procedure	(0040,1002)	LO				
Requested Procedure Priority	(0040,1003)	SH				
Patient Transport Arrangements	(0040,1004)	LO				
Requested Procedure Location	(0040,1005)	LO				
Placer Order Number / Procedure	(0040,1006)	SH				
Filler Order Number / Procedure	(0040,1007)	SH				
Confidentiality Code	(0040,1008)	LO				
Reporting Priority	(0040,1009)	SH				
Names of Intended Recipients of Results	(0040,1010)	PN				
Requested Procedure Comments	(0040,1400)	LT				
Imaging Service Request Module						
Accession Number	(0008,0050)	SH	S	x	x	x
Referring Physician's Name	(0008,0090)	PN		x	x	x
Requesting Physician	(0032,1032)	PN				
Requesting Service	(0032,1033)	LO				
Reason for the Imaging Service Request	(0040,2001)	LO				
Issue Date of Imaging Service Request	(0040,2004)	DA				
Issue Time of Imaging Service Request	(0040,2005)	TM				
Placer Order Number / Imaging Service Request	(0040,2006)	SH				
Filler Order Number / Imaging Service Request	(0040,2007)	SH				
Order Entered By	(0040,2008)	PN				
Order Enters Location	(0040,2009)	SH				
Order Callback Phone Number	(0040,2010)	SH				
Imaging Service Request Comments	(0040,2400)	LT				
Visit Relationship Module						
Referenced Patient Sequence	(0008,1120)	SQ				

Visit Identification Module							
Institution Name	(0008,0080)	LO					
Institution Address	(0008,0081)	ST					
Institution Code Sequence	(0008,0082)	SQ					
Admission ID	(0038,0010)	LO	X				
Issuer of Admission ID	(0038,0011)	LO					X
Visit Status Module							
Visit Status ID	(0038,0008)	CS					
Current Patient Location	(0038,0300)	LO	X				
Patient's Institution Residence	(0038,0400)	LO					X
Visit Comments	(0038,4000)	LT					
Visit Admission Module							
Referring Physician's Address	(0008,0092)	ST					
Referring Physician's Telephone Number	(0008,0094)	SH					
Admitting Diagnosis Description	(0008,1080)	LO					
Admitting Diagnosis Code Sequence	(0008,1084)	SQ					
Route of Admissions	(0038,0016)	LO					
Admitting Date	(0038,0020)	DA					
Admitting Time	(0038,0021)	TM					
Patient Relationship Module							
Referenced Visit Sequence	(0008,1125)	SQ					
Referenced Patient Alias Sequence	(0038,0004)	SQ					
Patient Identification Module							
Patient's Name	(0010,0010)	PN					
Patient ID	(0010,0020)	LO					
Issuer of Patient ID	(0010,0021)	LO					
Other Patient IDs	(0010,1000)	LO					
Other Patient Names	(0010,1001)	PN					
Patient's Birth Name	(0010,1005)	PN					
Patient's Mother's Birth Name	(0010,1060)	PN					
Medical Record Locator	(0010,1090)	LO					
Patient Demographic Module							
Patient's Birth Date	(0010,0030)	DA					
Patient's Birth Time	(0010,0032)	TM					
Patient's Sex	(0010,0040)	CS					
Patient's Insurance Plan Code Sequence	(0010,0050)	SQ					
Patient's Age	(0010,1010)	AS					
Patient's Size	(0010,1020)	DS					
Patient's Weight	(0010,1030)	DS					
Patient's Address	(0010,1040)	LO					
Military Rank	(0010,1080)	LO					
Branch of Service	(0010,1081)	LO					
Country Residence	(0010,2150)	LO					
Region of Residence	(0010,2152)	LO					
Patient's Telephone Number	(0010,2154)	SH					
Ethnic Group	(0010,2160)	SH					
Occupation	(0010,2180)	SH					
Patient's Religious Reference	(0010,21F0)	LO					
Patient Comments	(0010,4000)	LT					
Patient Data Confidentiality Constraint Description	(0040,3001)	LO					
Patient Medical Module							
Medical Alerts	(0010,2000)	LO					
Contrast Allergies	(0010,2110)	LO					
Smoking Status	(0010,21A0)	CS					
Additional Patient History	(0010,21B0)	LT					
Pregnancy Status	(0010,21C0)	US					
Last Menstrual Date	(0010,21D0)	DA					
Special Needs	(0038,0050)	LO					
Patient State	(0038,0500)	LO					

The above table should be read as follows:

- Module Name: The name of the associated module for supported worklist attributes.
- Attribute Name: Attributes supported to build the MWM SCU AE Worklist Request Identifier.
- Tag: DICOM tag for this attribute.
- VR: DICOM VR for this attribute.
- M: Matching keys for (automatic) Worklist Update.
S: Single Value Matching
R: Range Matching
W: Wild Card Matching
- R: Return keys. An "x" will indicate that the MWM SCU AE will supply this attribute as Return Key with zero length for Universal Matching.
- D: Displayed keys. An "x" indicates that this worklist attribute is displayed to the user during a patient registration. For example, Patient Name will be displayed when registering the patient prior to an examination.
- IOD: An "x" indicates that this worklist attribute is included into all Object Instances created during performance of the related Procedure Step.

4.2.5.4 Association Acceptance Policy

The MWM SCU AE does not accept associations.

4.2.6 MPPS SCU AE Specification

4.2.6.1 SOP Classes

The MPPS SCU AE provides Standard Conformance to the following SOP Classes:

**Table 4.2-44
SOP CLASSES FOR THE MPPS SCU AE**

SOP Class Name	SOP Class UID	SCU	SCP
Modality Performed Procedure Step	1.2.840.10008.3.1.2.3.3	Yes	No

4.2.6.2 Association Policies

4.2.6.2.1 General

The DICOM standard application context name for DICOM 3.0 is always proposed:

**Table 4.2-45
DICOM APPLICATION CONTEXT FOR THE MPPS SCU AE**

Application Context Name	1.2.840.10008.3.1.1.1
--------------------------	-----------------------

4.2.6.2.2 Number of Associations

The MPPS SCU AE initiates one association at a time.

**Table 4.2-46
NUMBER OF ASSOCIATIONS INITIATED FOR THE MPPS SCU AE**

Maximum number of simultaneous associations	1
---	---

4.2.6.2.3 Asynchronous Nature

The MPPS SCU AE does not support asynchronous communication (multiple outstanding transactions over a single association).

**Table 4.2-47
ASYNCHRONOUS NATURE FOR THE MPPS SCU AE**

Maximum number of outstanding asynchronous transactions	1
---	---

4.2.6.2.4 Implementation Identifying Information

The implementation information for this Application Entity is:

**Table 4.2-48
DICOM IMPLEMENTATION CLASS AND VERSION FOR THE MPPS SCU AE**

Implementation Class UID	2.16.124.113531.1.1
Implementation Version Name	Cedara RMA v3.0

4.2.6.3 Association Initiation Policy


4.2.6.3.1 Activity – Acquire Images

4.2.6.3.1.1 Description and Sequencing of Activities

The MPPS SCU AE performs the creation of an MPPS instance automatically when the user selects and starts a worklist item. Further updates on the MPPS data can be performed when the user completes the acquisition.

The MPPS SCU AE will initiate an association to issue an:

- N-CREATE request according to the CREATE Modality Performed Procedure Step SOP Instance operation, or an:
- N-SET request to update the contents and state of the MPPS according to the SET Modality Performed Procedure Step Information operation.



**Figure 4.2-7
SEQUENCING OF ACTIVITY – ACQUIRE IMAGES**

A possible sequence of interactions between the MPPS SCU AE and a Department Scheduler (e.g. a device such as a RIS or HIS which supports the MPPS SOP Class as an SCP) is illustrated in the Figure above:

1. The MPPS SCU AE opens an association with the Department Scheduler
2. The MPPS SCU AE sends an N-CREATE request to the Department Scheduler to create an MPPS instance with status of “IN PROGRESS” and create all necessary attributes. The Department Scheduler acknowledges the MPPS creation with an N-CREATE response (status success).
3. The MPPS SCU AE closes the association with the Department Scheduler.
4. All images are acquired and stored in the local database.
5. The MPPS SCU AE opens an association with the Department Scheduler.
6. The MPPS SCU AE sends an N-SET request to the Department Scheduler to update the MPPS instance with status of “COMPLETED” and set all necessary attributes. The Department Scheduler acknowledges the MPPS update with an N-SET response (status success).
7. The MPPS SCU AE closes the association with the Department Scheduler.

4.2.6.3.1.2 Proposed Presentation Contexts

The MPPS SCU AE will propose Presentation Contexts shown in the following table:

**Table 4.2-49
PROPOSED PRESENTATION CONTEXTS FOR REAL-WORLD ACTIVITY ACQUIRE IMAGES**

Presentation Context Table					
Abstract Syntax		Transfer Syntax		Role	Ext. Neg.
Name	UID	Name List	UID List		
Modality Performed Procedure Step	1.2.840.10008.3.1.2.3.3	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None

4.2.6.3.1.3 SOP Specific Conformance for MPPS SOP Class

The MPPS SCU AE provides standard conformance to the Modality Performed Procedure Step SOP Class as an SCU.

The behavior of the MPPS SCU AE when encountering status codes in an MPPS N-CREATE or N-SET response is summarized in the table below.

**Table 4.2-50
MPPS N-CREATE / N-SET RESPONSE STATUS HANDLING BEHAVIOR**

Service Status	Further Meaning	Status Code	Behavior
Success	Success	0000	The SCP has completed the operation successfully.
*	*	Any other status code	The association is aborted and the MPPS is marked as failed. The status meaning is logged and reported to the user.

The behavior of the MPPS SCU AE during communication failure is summarized in the table below:

**Table 4.2-51
MPPS COMMUNICATION FAILURE BEHAVIOR**

Exception	Behavior
Timeout	The association is aborted and MPPS is marked as failed. The reason is logged and reported to the user.
Association aborted by the SCP or network layers	The MPPS is marked as failed. The reason is logged and reported to the user.

The table below provides a description of the MPPS N-CREATE and N-SET request identifiers sent by the MPPS SCU AE. Empty cells in the N-CREATE and N-SET columns indicate that the attribute is not sent. An "x" indicates that an appropriate value will be sent. A "Zero length" attribute will be sent with zero length.

Table 4.2-52
MPPS N-CREATE / N-SET REQUEST IDENTIFIER

Attribute Name	Tag	VR	N-CREATE	N-SET
Specific Character Set	(0008,0005)	CS	ISO_IR 100	
Performed Procedure Step Relationship				
Scheduled Step Attributes Sequence	(0040,0270)	SQ	Always Set	
> Study Instance UID	(0020,000D)	UI	From Modality Worklist	
> Referenced Study Sequence	(0008,1110)	SQ	From Modality Worklist	
>> Referenced SOP Class UID	(0008,1150)	UI	From Modality Worklist	
>> Referenced SOP Instance UID	(0008,1155)	UI	From Modality Worklist	
> Accession Number	(0008,0050)	SH	From Modality Worklist	
> Placer Order Number/Imaging Service Request	(0040,2016)	LO		
> Filler Order Number/Imaging Service Request	(0040,2017)	LO		
> Requested Procedure ID	(0040,1001)	SH	From Modality Worklist	
> Requested Procedure Description	(0032,1060)	LO	From Modality Worklist	
> Scheduled Procedure Step ID	(0040,0009)	SH	Zero length	
> Scheduled Procedure Step Description	(0040,0007)	LO	Zero length	
> Scheduled Protocol Code Sequence	(0040,0008)	SQ		
Patient's Name	(0010,0010)	PN	From Modality Worklist or user input	
Patient ID	(0010,0020)	LO	From Modality Worklist or user input.	
Patient's Birth Date	(0010,0030)	DA	From Modality Worklist or user input.	
Patient's Sex	(0010,0040)	CS	From Modality Worklist or user input.	
Referenced Patient Sequence	(0008,1120)	SQ	From Modality Worklist.	
Performed Procedure Step Information				
Performed Procedure Step ID	(0040,0253)	SH	Automatically created.	
Performed Station AE Title	(0040,0241)	AE	MPPS AE Title	
Performed Station Name	(0040,0242)	SH	From configuration	
Performed Location	(0040,0243)	SH	Zero length	
Performed Procedure Step Start Date	(0040,0244)	DA	Actual start date	
Performed Procedure Step Start Time	(0040,0245)	TM	Actual start time	
Performed Procedure Step Status	(0040,0252)	CS	IN PROGRESS	COMPLETED or DISCONTINUED

Performed Procedure Step Description	(0040,0254)	LO	Zero length	
Performed Procedure Type Description	(0040,0255)	LO	Zero length	
Procedure Code Sequence	(0008,1032)	SQ	Zero or more items	Zero or more items
Performed Procedure Step End Date	(0040,0250)	DA	Zero length	Actual end date
Performed Procedure Step End Time	(0040,0251)	TM	Zero length	Actual end time
Image Acquisition Results				
Modality	(0008,0060)	CS	US	
Study ID	(0020,0010)	SH	From Modality Worklist or automatically created.	
Performed Protocol Code Sequence	(0040,0260)	SQ	Zero or more items	Zero or more items
Performed Series Sequence	(0040,0340)	SQ	Zero length	One or more items
> Performing Physician's Name	(0008,1050)	PN		Zero length
> Protocol Name	(0018,1030)	LO		x
> Operator's Name	(0008,1070)	PN		Zero length
> Series Instance UID	(0020,000E)	UI		x
> Series Description	(0008,103E)	LO		Zero length
> Retrieve AE Title	(0008,0054)	AE		Zero length
> Referenced Image Sequence	(0008,1140)	SQ		One or more items
>> Referenced SOP Class UID	(0008,1150)	UI		x
>> Referenced SOP Instance UID	(0008,1155)	UI		x
> Referenced Non-Image Composite SOP Instance Sequence	(0040,0220)	SQ		Zero length
>> Referenced SOP Class UID	(0008,1150)	UI		
>> Referenced SOP Instance UID	(0008,1155)	UI		
Billing and Material Code				
Film Consumption Sequence	(0040,0321)	SQ		
>Number of Films	(2100,0170)	IS		
>Medium Type	(2000,0030)	CS		
>Film Size ID	(2010,0050)	CS		
Billing Supplies and Devices Sequence	(0040,0324)	SQ		
>Quantity Sequence	(0040,0293)	SQ		
>>Quantity	(0040,0294)	DS		
>>Measuring Units Sequence	(0040,0295)	SQ		

4.2.6.4 Association Acceptance Policy

The MPPS SCU AE does not accept associations.

4.2.7 Q/R SCU AE Specification

4.2.7.1 SOP Classes

The Q/R SCU AE provides Standard Conformance to the following SOP Classes:

**Table 4.2-53
SOP CLASSES FOR THE Q/R SCU AE**

SOP Class Name	SOP Class UID	SCU	SCP
Study Root Q/R Information Model – Find	1.2.840.10008.5.1.4.1.2.2.1		Yes
Study Root Q/R Information Model – Move	1.2.840.10008.5.1.4.1.2.2.2		

4.2.7.2 Association Policies

4.2.7.2.1 General

The DICOM standard application context name for DICOM 3.0 is always proposed:

**Table 4.2-54
DICOM APPLICATION CONTEXT FOR THE Q/R SCU AE**

Application Context Name	1.2.840.10008.3.1.1.1
--------------------------	-----------------------

4.2.7.2.2 Number of Associations

The Q/R SCU AE initiates one association at a time.

**Table 4.2-55
NUMBER OF ASSOCIATIONS INITIATED FOR THE Q/R SCU AE**

Maximum number of simultaneous associations	1
---	---

4.2.7.2.3 Asynchronous Nature

The Q/R SCU AE does not support asynchronous communication (multiple outstanding transactions over a single association).

**Table 4.2-56
ASYNCHRONOUS NATURE FOR THE Q/R SCU AE**

Maximum number of outstanding asynchronous transactions	1
---	---

4.2.7.2.4 Implementation Identifying Information

The implementation information for this Application Entity is:

**Table 4.2-57
DICOM IMPLEMENTATION CLASS AND VERSION FOR THE Q/R SCU AE**

Implementation Class UID	2.16.124.113531.1.1
Implementation Version Name	Cedara RMA v3.0

4.2.7.3 Association Initiation Policy

4.2.7.3.1 Activity – Query and Retrieve Images

The Q/R SCU AE is activated when the user selects a remote node to query and enters some key information, Patient's Name, Patient ID and/or Accession Number. The user can select studies, series and images to be retrieved. The images will be received at the Storage SCP AE.




Figure 4.2-8
SEQUENCING OF ACTIVITY – QUERY AND RETRIEVE IMAGES

The following sequencing constraints illustrated in the Figure above:

1. The Q/R SCU AE opens an association with the Q/R SCP AE.
2. The Q/R SCU AE sends a C-FIND-RQ Message
3. The Q/R SCP AE returns a C-FIND-RSP Message to the Q/R SCU AE with matching information. A C-FIND-RSP is sent for each entity matching the identifier specified in the C-FIND-RQ. A final C-FIND-RSP is sent indicating that the matching is complete.
4. The Q/R SCU AE closes the association.
5. The Q/R SCU AE opens an association with the Q/R SCP AE.
6. The Q/R SCU AE sends a C-MOVE-RQ Message. The Q/R SCP AE notifies the Storage SCU AE to send the Composite SOP Instances to the peer C-MOVE Destination AE as indicated in the C-MOVE-RQ.
7. The Storage SCU AE opens an association with the C-MOVE Destination AE.
8. The Storage SCU AE sends images to the C-MOVE Destination AE. The Storage SCU AE indicates to the Q/R SCP AE whether the transfer succeeded or failed.
9. The Q/R SCP AE then returns a C-MOVE-RSP indicating this success or failure.
10. The Storage SCU AE closes the association.
11. The Q/R SCU AE closes the association.

4.2.7.3.1.2 Proposed Presentation Contexts

The Q/R SCU AE will propose Presentation Contexts shown in the following table:

**Table 4.2-58
PROPOSED PRESENTATION CONTEXTS FOR REAL-WORLD ACTIVITY
QUERY AND RETRIEVE IMAGES**

Presentation Context Table					
Abstract Syntax		Transfer Syntax		Role	Ext. Neg.
Name	UID	Name List	UID List		
Study Root Q/R Information Model – Find	1.2.840.10008.5.1.4.1.2.2.1	Implicit VR Little Endian	1.2.840.10008.1.2	SCU	None
Study Root Q/R Information Model – Move	1.2.840.10008.5.1.4.1.2.2.2	Implicit VR Little Endian	1.2.840.10008.1.2		

4.2.7.3.1.3 SOP Specific Conformance for Q/R Find SOP Classes

The Q/R SCU AE provides standard conformance to the Query/Retrieve Find SOP Classes as an SCU.

The behavior of the Q/R SCU AE when encountering status codes in a Q/R C-FIND response is summarized in the table below:

**Table 4.2-59
THE Q/R SCU AE C-FIND RESPONSE STATUS BEHAVIOR**

Service Status	Further Meaning	Status Code	Behavior
Success	Matching is complete	0000	The SCP has completed the matches. Worklist items are available for display or further processing.
*	*	Any other status code	The association is aborted using A-ABORT and the worklist query is marked as failed. The status meaning is logged and reported to the user.

The behavior of the Q/R SCU AE during communication failure is summarized in the table below.

**Table 4.2-60
Q/R FIND COMMUNICATION FAILURE BEHAVIOR**

Exception	Behavior
Timeout	The association is aborted and the study, series or image query is marked as failed. The reason is logged and reported to the user.
Association aborted by the SCP or network layers	The study, series or image query is marked as failed. The reason is logged and reported to the user.

All queries are initiated at the highest level of the information model (the STUDY level).

The table below provides a description of the Q/R SCU AE C-FIND Request Identifier.

**Table 4.2-61
STUDY ROOT REQUEST IDENTIFIER FOR C-FIND**

Name	Tag	Types of Matching
Study Level		
Study Date	(0008,0020)	U
Study Time	(0008,0030)	U
Accession Number	(0008,0050)	S,U
Study Description	(0008,1030)	U
Patient's Name	(0010,0010)	S,*,U
Patient's ID	(0010,0020)	S,U
Patient's Sex	(0010,0040)	U
Study Instance UID	(0020,000D)	U
Study ID	(0020,0010)	U
Number of Study Related Instances	(0020,1208)	U

Types of Matching:

The types of Matching supported by the Q/R SCU AE. An "S" indicates the identifier attribute uses Single Value Matching, an "R" indicates Range Matching, an "*" indicates wildcard matching, and a 'U' indicates Universal Matching.

4.2.7.3.1.4 SOP Specific Conformance for Q/R Move SOP Classes

The Q/R SCU AE provides standard conformance to the Query/Retrieve Move SOP Classes as an SCU.

The behavior of the Q/R SCU AE when encountering status codes in a Q/R C-MOVE response is summarized in the table below:

**Table 4.2-62
THE Q/R SCU AE C-MOVE RESPONSE STATUS BEHAVIOR**

Service Status	Further Meaning	Status Code	Behavior
Success	Sub-operations complete – No Failures	0000	The Storage SCP AE has successfully received the SOP Instance. If all SOP Instances in a move job have status success then the job is marked as complete.
*	*	Any other status code	The association is aborted using A-ABORT and the move job is marked as failed. The status meaning is logged and the job failure is reported to the user via the job control application.

The behavior of the Q/R SCU AE during communication failure is summarized in the table below.

**Table 4.2-63
Q/R MOVE COMMUNICATION FAILURE BEHAVIOR**

Exception	Behavior
Timeout	The association is aborted using A-ABORT and the retrieve is marked as failed. The reason is logged and reported to the user if an interactive query.
Association aborted by the SCP or network layers	The retrieve is marked as failed. The reason is logged and reported to the user if an interactive query.

The system requests Image Level Move only.

4.2.7.4 Association Acceptance Policy

The Q/R SCU AE does not accept associations.

4.2.8 Storage SCP AE Specification

4.2.8.1 SOP Classes

The Storage SCP AE provides Standard Conformance to the following SOP Classes:

**Table 4.2-64
SOP CLASSES FOR THE STORAGE SCP AE**

SOP Class Name	SOP Class UID	SCU	SCP
Secondary Capture Image Storage	1.2.840.10008.5.1.4.1.1.7	No	Yes
Ultrasound Image Storage (retired)	1.2.840.10008.5.1.4.1.1.6		
Ultrasound Image Storage	1.2.840.10008.5.1.4.1.1.6.1		
Ultrasound Multi-frame Image Storage (retired)	1.2.840.10008.5.1.4.1.1.3		
Ultrasound Multi-frame Image Storage	1.2.840.10008.5.1.4.1.1.3.1		
Enhanced SR Storage	1.2.840.10008.5.1.4.1.1.88.22		

4.2.8.2 Association Policies

4.2.8.2.1 General

The DICOM standard application context name for DICOM 3.0 is always proposed:

**Table 4.2-65
DICOM APPLICATION CONTEXT FOR THE STORAGE SCP AE**

Application Context Name	1.2.840.10008.3.1.1.1
--------------------------	-----------------------

4.2.8.2.2 Number of Associations

The Storage SCP AE supports one association at a time.

**Table 4.2-66
NUMBER OF ASSOCIATIONS ACCEPTED FOR THE STORAGE SCP AE**

Maximum number of simultaneous associations	1
---	---

4.2.8.2.3 Asynchronous Nature

The Storage SCP AE does not support asynchronous communication (multiple outstanding transactions over a single association).

**Table 4.2-67
ASYNCHRONOUS NATURE FOR THE STORAGE SCP AE**

Maximum number of outstanding asynchronous transactions	1
---	---

4.2.8.2.4 Implementation Identifying Information

The implementation information for the Storage SCP AE is:

**Table 4.2-68
DICOM IMPLEMENTATION CLASS AND VERSION FOR THE STORAGE SCP AE**


Implementation Class UID	2.16.124.113531.1.1
Implementation Version Name	Cedara RMA v3.0

4.2.8.3 Association Initiation Policy

The Storage SCP AE does not initiate associations.

4.2.8.4 Association Acceptance Policy

The Storage SCP AE accepts associations only if they have valid Presentation Contexts. If none of the requested Presentation Contexts are accepted then the association request itself is rejected. It can be configured to only accept associations with certain hosts (using TCP/IP address) and/or AE Titles.



**Figure 4.2-9
SEQUENCING OF ACTIVITY – STORE IMAGES TO THE LOCAL FILE SYSTEM**

A possible sequence of interactions between the Storage SCP AE and a Storage SCU AE is illustrated in the Figure above:

1. The Storage SCU AE opens an association with the Storage SCP AE.
2. The Storage SCU AE sends images to the Storage SCP AE using a storage request (C-STORE) and the Storage SCP AE replies with a C-STORE response (status success).
3. The Storage SCU AE closes the association with the Storage SCP AE.

The Storage SCP AE does not care about a called/calling AE title contained in association requests.

4.2.8.4.1.1 Accepted Presentation Contexts

The default behavior of the Storage SCP AE supports the Implicit VR Little Endian and Explicit VR Little Endian transfer syntaxes. If the both transfer syntaxes are proposed per presentation context then the Storage SCP AE will select Explicit VR Little Endian Transfer Syntax.

Any of the presentation contexts shown in the following table are acceptable to the Storage SCP AE.

**Table 4.2-69
ACCEPTED PRESENTATION CONTEXTS BY THE STORAGE SCP AE**

Presentation Context Table					
Abstract Syntax		Transfer Syntax		Role	Ext. Neg.
Name	UID	Name List	UID List		
Secondary Capture Image Storage	1.2.840.10008.5.1.4.1.1.7	Implicit VR Little Endian	1.2.840.10008.1.2	SCP	None
		Explicit VR Little Endian	1.2.840.10008.1.2.1		
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50		
		RLE Lossless	1.2.840.10008.1.2.5		
Ultrasound Image Storage (retired)	1.2.840.10008.5.1.4.1.1.6	Implicit VR Little Endian	1.2.840.10008.1.2	SCP	None
		Explicit VR Little Endian	1.2.840.10008.1.2.1		
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50		
		RLE Lossless	1.2.840.10008.1.2.5		
Ultrasound Image Storage	1.2.840.10008.5.1.4.1.1.6.1	Implicit VR Little Endian	1.2.840.10008.1.2	SCP	None
		Explicit VR Little Endian	1.2.840.10008.1.2.1		
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50		
		RLE Lossless	1.2.840.10008.1.2.5		
Ultrasound Multi-frame Image Storage (retired)	1.2.840.10008.5.1.4.1.1.3	Implicit VR Little Endian	1.2.840.10008.1.2	SCP	None
		Explicit VR Little Endian	1.2.840.10008.1.2.1		
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50		
		RLE Lossless	1.2.840.10008.1.2.5		
Ultrasound Multi-frame Image Storage	1.2.840.10008.5.1.4.1.1.3.1	Implicit VR Little Endian	1.2.840.10008.1.2	SCP	None
		Explicit VR Little Endian	1.2.840.10008.1.2.1		
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50		
		RLE Lossless	1.2.840.10008.1.2.5		
Enhanced SR Storage	1.2.840.10008.5.1.4.1.1.88.22	Implicit VR Little Endian	1.2.840.10008.1.2	SCP	None
		Explicit VR Little Endian	1.2.840.10008.1.2.1		

4.2.8.4.1.2 SOP Specific Conformance for Storage SOP Classes

The associated Activity with the Storage service is the storage of medical image data received over the network on a designated hard disk. The Storage SCP AE will return a failure status if it is unable to store the images on to the hard disk.

The Storage SCP AE is Level 0 conformant as a Storage SCP.

**Table 4.2-70
THE STORAGE SCP AE C-STORE RESPONSE STATUS RETURN REASONS**

Service Status	Further Meaning	Status Code	Reason
Success	Success	0000	The Composite SOP Instance was successfully received, verified, and stored in the system database.
Refused	Out of Resources	A700	Indicates that there was not enough local resources.
Error	Cannot Understand	C000	Indicates that the Storage SCP AE cannot parse the Data Set into Elements.

4.2.9 Print SCU AE Specification

4.2.9.1 SOP Classes

The Print SCU AE provides Standard Conformance to the following Meta SOP Classes:

**Table 4.2-71
META SOP CLASSES FOR THE PRINT SCU AE**

SOP Class Name	SOP Class UID	SCU	SCP
Basic Grayscale Print Management Meta	1.2.840.10008.5.1.1.9	Yes	No
Basic Color Print Management Meta	1.2.840.10008.5.1.1.18	Yes	No

The above Meta SOP Classes are defined by the following set of supported SOP Classes:

**Table 4.2-72
SOP CLASSES FOR THE PRINT SCU AE**

SOP Class Name	SOP Class UID	SCU	SCP
Basic Film Session SOP Class	1.2.840.10008.5.1.1.1	Yes	No
Basic Film Box SOP Class	1.2.840.10008.5.1.1.2	Yes	No
Basic Grayscale Image Box SOP Class	1.2.840.10008.5.1.1.4	Yes	No
Basic Color Image Box SOP Class	1.2.840.10008.5.1.1.4.1	Yes	No
Printer SOP Class	1.2.840.10008.5.1.1.16	Yes	No

4.2.9.2 Association Policies

4.2.9.2.1 General

The DICOM standard application context name for DICOM 3.0 is always proposed:

**Table 4.2-73
DICOM APPLICATION CONTEXT FOR THE PRINT SCU AE**

Application Context Name	1.2.840.10008.3.1.1.1
--------------------------	-----------------------

4.2.9.2.2 Number of Associations

The Print SCU AE initiates one association at a time.

**Table 4.2-74
NUMBER OF ASSOCIATIONS INITIATED FOR THE PRINT SCU AE**

Maximum number of simultaneous associations	1
---	---

4.2.9.2.3 Asynchronous Nature

The Print SCU AE does not support asynchronous communication (multiple outstanding transactions over a single association).

**Table 4.2-75
ASYNCHRONOUS NATURE FOR THE PRINT SCU AE**

Maximum number of outstanding asynchronous transactions	1
---	---

4.2.9.2.4 Implementation Identifying Information

The implementation information for the Print SCU AE is:

**Table 4.2-76
DICOM IMPLEMENTATION CLASS AND VERSION FOR THE PRINT SCU AE**


Implementation Class UID	2.16.124.113531.1.1
Implementation Version Name	Cedara RMA v3.0

4.2.9.3 Association Initiation Policy

4.2.9.3.1 Activity – Send Images & Print Management Information

4.2.9.3.1.1 Description and Sequencing of Activities

A user composes images onto film sheets and requests them to be sent to a specific hardcopy device. The user can select the desired film format and number of copies.



**Figure 4.2-10
SEQUENCING OF ACTIVITY – SEND IMAGES & PRINT MANAGEMENT INFORMATION**

A typical sequence of DIMSE messages sent over an association between the Print SCU AE and a Printer is illustrated in the Figure above:

1. The Print SCU AE opens an association with the Printer.
2. N-GET on the Printer SOP Class is used to obtain current printer status information.
3. N-CREATE on the Film Session SOP Class creates a Film Session.
4. N-CREATE on the Film Box SOP Class creates a Film Box linked to the Film Session.
5. N-SET on the Image Box SOP Class transfers the contents of the film sheet to the printer.
6. N-ACTION on the Film Box SOP Class instructs the Printer to print the Film Box.
7. The Printer prints the requested number of film sheets.
8. The Print SCU AE closes the association with the Printer.

4.2.9.3.1.2 Proposed Presentation Contexts

The Print SCU AE will propose the Presentation Contexts shown in the following table:

**Table 4.2-77
PROPOSED PRESENTATION CONTEXTS FOR ACTIVITY
SEND IMAGES & PRINT MANAGEMENT INFORMATION**

Presentation Context Table					
Abstract Syntax		Transfer Syntax		Role	Ext. Neg.
Name	UID	Name List	UID List		
Basic Grayscale Print Management Meta	1.2.840.10008.5.1.1.9	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None
Basic Color Print Management Meta	1.2.840.10008.5.1.1.18	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None
Print Job SOP Class	1.2.840.10008.5.1.1.14	Implicit VR LittleEndian	1.2.840.10008.1.2	SCU	None

4.2.9.3.1.3 Common SOP Specific Conformance for all Print SOP Classes

The general behavior of the Print SCU AE during communication failure is summarized in the table below. This behavior is common for all SOP Classes supported by the Print SCU AE.

**Table 4.2-78
PRINT COMMUNICATION FAILURE BEHAVIOR**

Exception	Behavior
Timeout	The association is aborted and the print-job is marked as failed. The reason is logged and the job failure is reported to the user via the job control application.
Association aborted by the SCP or network layers	The print-job is marked as failed. The reason is logged and the job failure is reported to the user via the job control application.

4.2.9.3.1.4 SOP Specific Conformance for Printer SOP Class

The Print SCU AE supports the following DIMSE operations and notifications for the Printer SOP Class:

- N-GET

Details of the supported attributes and status handling behavior are described in the following subsections.

4.2.9.3.1.4.1 Printer SOP Class Operations (N-GET)

The Print SCU AE uses the Printer SOP Class N-GET operation to obtain information about the current printer status. The attributes obtained via N-GET are listed in the table below:

**Table 4.2-79
PRINTER SOP CLASS N-GET REQUEST ATTRIBUTES**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Printer Status	(2110,0010)	CS	Provided by Printer	ALWAYS	Printer
Printer Status Info	(2110,0020)	CS	Provided by Printer	ALWAYS	Printer

The Printer Status information is evaluated as follows:

1. If Printer Status (2110,0010) is NORMAL, the print-job continues to be printed.
2. If Printer Status (2110,0010) is FAILURE or WARNING, the Print SCU AE retries the print-job automatically.

The behavior of The Print SCU AE when encountering status codes in an N-GET response is summarized in the table below:

**Table 4.2-80
PRINTER SOP CLASS N-GET RESPONSE STATUS HANDLING BEHAVIOR**

Service Status	Further Meaning	Status Code	Behavior
Success	Success	0000	The request to get printer status information was success.
*	*	Any other status code	The association is aborted using A-ABORT and the print-job is marked as failed. The status meaning is logged and reported to the user.

4.2.9.3.1.5 SOP Specific Conformance for the Film Session SOP Class

The Print SCU AE supports the following DIMSE operations for the Film Session SOP Class:

- N-CREATE

Details of the supported attributes and status handling behavior are described in the following subsections.

4.2.9.3.1.5.1 Film Session SOP Class Operations (N-CREATE)

The attributes supplied in an N-CREATE Request are listed in the table below:

**Table 4.2-81
FILM SESSION SOP CLASS N-CREATE REQUEST ATTRIBUTES**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Number of Copies	(2000,0010)	IS	1	ALWAYS	AUTO
Medium Type	(2000,0030)	CS	BLUE FILM, CLEAR FILM or PAPER	ALWAYS	USER

The behavior of The Print SCU AE when encountering status codes in a N-CREATE response is summarized in the table below:

**Table 4.2-82
FILM SESSION SOP CLASS N-CREATE RESPONSE STATUS HANDLING BEHAVIOR**

Service Status	Further Meaning	Status Code	Behavior
Success	Success	0000	The SCP has completed the operation successfully.
*	*	Any other status code	The association is aborted using A-ABORT and the print-job is marked as failed. The status meaning is logged and reported to the user.

4.2.9.3.1.6 SOP Specific Conformance for the Film Box SOP Class

The Print SCU AE supports the following DIMSE operations for the Film Box SOP Class:

- N-CREATE
- N-ACTION

Details of the supported attributes and status handling behavior are described in the following subsections.

4.2.9.3.1.6.1 Film Box SOP Class Operations (N-CREATE)

The attributes supplied in an N-CREATE Request are listed in the table below:

**Table 4.2-83
FILM BOX SOP CLASS N-CREATE REQUEST ATTRIBUTES**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Image Display Format	(2010,0010)	ST	STANDARD\{C,R (C,R) is (1,1) (1,2) (2,2) (2,3) (2,4) (3,4) (3,5) (4,4) (4,5) (4,6) (5,5) (5,6) for Film Orientation PORTRAIT, and (1,1) (2,1) (2,2) (3,2) (4,2) (4,3) (5,3) (4,4) (5,4) (6,4) (5,5) (6,5) for LANDSCAPE.	ALWAYS	USER
Film Orientation	(2010,0040)	CS	PORTRAIT or LANDSCAPE	ALWAYS	USER
Film Size ID	(2010,0050)	CS	8INX10IN, 10INX12IN, 10INX14IN, 11INX14IN, 14INX14IN, or 14INX17IN	ALWAYS	USER
Magnification Type	(2010,0060)	CS	REPLICATE, BILINEAR, CUBIC or NONE	ALWAYS	CONFIG
Min Density	(2010,0120)	US		ALWAYS	CONFIG
Max Density	(2010,0130)	US		ALWAYS	CONFIG
Referenced Film Session Sequence	(2010,0500)	SQ		ALWAYS	AUTO
>Referenced SOP Class UID	(0008,1150)	UI	1.2.840.10008.5.1.1.1	ALWAYS	AUTO
>Referenced SOP Instance UID	(0008,1155)	UI	From created Film Session SOP Instance	ALWAYS	AUTO

The behavior of the Print SCU AE when encountering status codes in a N-CREATE response is summarized in the table below:

**Table 4.2-84
FILM BOX SOP CLASS N-CREATE RESPONSE STATUS HANDLING BEHAVIOR**

Service Status	Further Meaning	Status Code	Behavior
Success	Success	0000	The SCP has completed the operation successfully.
*	*	Any other status code	The association is aborted and the print-job is marked as failed. The status meaning is logged and reported to the user.

4.2.9.3.1.6.2 Film Box SOP Class Operations (N-ACTION)

An N-ACTION Request is issued to instruct the Print SCP to print the contents of the Film Box. The Action Reply argument in an N-ACTION response is not evaluated.

The behavior of The Print SCU AE when encountering status codes in a N-ACTION response is summarized in the table below:

Table 4.2-85
FILM BOX SOP CLASS N-ACTION RESPONSE STATUS HANDLING BEHAVIOR

Service Status	Further Meaning	Status Code	Behavior
Success	Success	0000	The SCP has completed the operation successfully. The film has been accepted for printing.
*	*	Any other status code	The association is aborted and the print-job is marked as failed. The status meaning is logged and reported to the user.

4.2.9.3.1.7 SOP Specific Conformance for the Grayscale Image Box SOP Class

The Print SCU AE supports the following DIMSE operations for the Grayscale Image Box SOP Class:

— N-SET

Details of the supported attributes and status handling behavior are described in the following subsections.

4.2.9.3.1.7.1 Grayscale Image Box SOP Class Operations (N-SET)

The attributes supplied in an N-SET Request are listed in the table below:

**Table 4.2-86
GRAYSCALE IMAGE BOX SOP CLASS N-SET REQUEST ATTRIBUTES**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Image Position	(2020,0010)	US	1 .. 30	ALWAYS	AUTO
Basic Grayscale Image Sequence	(2020,0110)	SQ		ALWAYS	AUTO
>Samples Per Pixel	(0028,0002)	US	1	ALWAYS	AUTO
>Photometric Interpretation	(0028,0004)	CS	MONOCHROME2	ALWAYS	AUTO
>Rows	(0028,0010)	US	480	ALWAYS	AUTO
>Columns	(0028,0011)	US	640	ALWAYS	AUTO
>Pixel Aspect Ratio	(0028,0034)	IS	1\1	ALWAYS	AUTO
>Bits Allocated	(0028,0100)	US	8	ALWAYS	AUTO
>Bits Stored	(0028,0101)	US	8	ALWAYS	AUTO
>High Bit	(0028,0102)	US	7	ALWAYS	AUTO
>Pixel Representation	(0028,0103)	US	0	ALWAYS	AUTO
>Pixel Data	(7FE0,0010)	OW		ALWAYS	AUTO

The behavior of the Print SCU AE when encountering status codes in a N-SET response is summarized in the table below:

**Table 4.2-87
GRAYSCALE IMAGE BOX SOP CLASS N-SET RESPONSE STATUS HANDLING BEHAVIOR**

Service Status	Further Meaning	Status Code	Behavior
Success	Success	0000	The SCP has completed the operation successfully. Image successfully stored in Image Box.
*	*	Any other status code	The association is aborted and the print-job is marked as failed. The status meaning is logged and reported to the user.

4.2.9.3.1.8 SOP Specific Conformance for the Color Image Box SOP Class

The Print SCU AE supports the following DIMSE operations for the Color Image Box SOP Class:

— N-SET

Details of the supported attributes and status handling behavior are described in the following subsections.

4.2.9.3.1.8.1 Color Image Box SOP Class Operations (N-SET)

The attributes supplied in an N-SET Request are listed in the table below:

**Table 4.2-88
COLOR IMAGE BOX SOP CLASS N-SET REQUEST ATTRIBUTES**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Image Position	(2020,0010)	US	1 .. 30	ALWAYS	AUTO
Basic Color Image Sequence	(2020,0111)	SQ		ALWAYS	AUTO
>Samples Per Pixel	(0028,0002)	US	3	ALWAYS	AUTO
>Photometric Interpretation	(0028,0004)	CS	RGB	ALWAYS	AUTO
>Planar Configuration	(0028,0006)	US	0	ALWAYS	AUTO
>Rows	(0028,0010)	US	480	ALWAYS	AUTO
>Columns	(0028,0011)	US	640	ALWAYS	AUTO
>Pixel Aspect Ratio	(0028,0034)	IS	1\1	ALWAYS	AUTO
>Bits Allocated	(0028,0100)	US	8	ALWAYS	AUTO
>Bits Stored	(0028,0101)	US	8	ALWAYS	AUTO
>High Bit	(0028,0102)	US	7	ALWAYS	AUTO
>Pixel Representation	(0028,0103)	US	0	ALWAYS	AUTO
>Pixel Data	(7FE0,0010)	OW		ALWAYS	AUTO

The behavior of the Print SCU AE when encountering status codes in a N-SET response is summarized in the table below:

**Table 4.2-89
COLOR IMAGE BOX SOP CLASS N-SET RESPONSE STATUS HANDLING BEHAVIOR**

Service Status	Further Meaning	Status Code	Behavior
Success	Success	0000	The SCP has completed the operation successfully. Image successfully stored in Image Box.
*	*	Any other status code	The association is aborted and the print-job is marked as failed. The status meaning is logged and reported to the user.

4.2.9.4 Association Acceptance Policy

The Print SCU AE does not accept associations.

4.3 NETWORK INTERFACES

4.3.1 Physical Network Interface

This product supports a single network interface. One of the following physical network interfaces will be available depending on installed hardware options:

**Table 4.3-1
SUPPORTED PHYSICAL NETWORK INTERFACES**

Ethernet 100baseT
Ethernet 10baseT

4.3.2 Additional Protocols

None.

4.4 CONFIGURATION

4.4.1 AE Title/Presentation Address Mapping

4.4.1.1 Local AE Titles

All local applications use the AE Titles and TCP/IP Ports configured via the Service Tool. The Field Service Engineer can configure the TCP Port via the Service Tool.

**Table 4.4-1
AE TITLE CONFIGURATION TABLE**

Application Entity	Default AE Title	Default TCP/IP Port
MWM SCU	TOSHIBAxxxxxx	Not Applicable
MPPS SCU		
Q/R SCU		
Print SCU		
Storage SCU		
Storage SCP		
Storage Commitment SCU		104

4.4.1.2 Remote AE Title/Presentation Address Mapping

The AE Titles, host names and port numbers of remote applications are configured using the Service Tool.

4.4.2 Parameters

A large number of parameters related to acquisition and general operation can be configured using the Service Tool. The table below only shows those configuration parameters relevant to DICOM communication. See the Product's Service Manual for details on general configuration capabilities.


**Table 4.4-2
CONFIGURATION PARAMETERS TABLE**

Parameter	Configurable (Yes/No) [Range]	Default Value
General Parameters		
MAX PDU Receive Size	Yes [1-9999]	32 Kbytes
MAX PDU Send Size		
Time-out waiting for an acceptance response to an association request (Application Level Timeout)	Yes [1-9999]	30 sec
Number of times a failed job may be retried	No	Forever, until the job succeeds or user deletes the job.
Delay between retrying failed jobs	No	60 sec.
Storage SCU Parameters		
Maximum number of simultaneously initiated associations by the Storage SCU AE	No	1
Supported transfer syntaxes	Yes	Implicit VR LittleEndian
Storage Commitment SCU Parameters		
Maximum number of simultaneously initiated associations by the Storage Commitment SCU AE	No	1
Maximum number of simultaneously accepted associations by the Storage Commitment SCU AE	No	1
Delay association release after sending a storage commitment request (wait for a storage commitment notification over the same association)	Yes	0 sec
Modality Worklist SCU Parameters		
Maximum number of simultaneously initiated associations by the MWM SCU AE	No	1
Supported transfer syntaxes for MWM	No	Implicit VR LittleEndian
Maximum number of worklist items	No	500
Query worklist for specific Scheduled Station AE Title	Yes	TOSHIBAxxxxxx
Query worklist for specific Modality	No	US
MPPS SCU Parameters		
Maximum number of simultaneously initiated associations by the MPPS SCU AE	No	1
Supported transfer syntaxes for MPPS	No	Implicit VR LittleEndian
Storage SCP parameters		
Maximum number of simultaneously accepted associations by the Storage SCP AE	No	1
Print SCU Parameters		
Maximum number of simultaneously initiated associations by the Print SCU AE	No	1
Supported transfer syntaxes for Print	No	Implicit VR LittleEndian

5. MEDIA INTERCHANGE

5.1 IMPLEMENTATION MODEL

5.1.1 Application Data Flow



**Figure 5.1-1
APPLICATION DATA FLOW DIAGRAM FOR MEDIA STORAGE**

- The Offline-Media AE exports image files to a CD-R or a DVD+R Storage medium. It is associated with the local real-world activity “Export Image Files” performed upon user request.
- The Offline-Media AE imports image files from a CD-R or a DVD+R Storage medium. It is associated with the local real-world activity “Import Image Files” performed upon user request.

5.1.2 Functional Definition of AEs

5.1.2.1 Functional Definition of Offline-Media AE

The Offline-Media AE is performed upon user request for selected studies/series/images to/from an offline DICOM CD-R or DVD+R medium. It therefore performs the following tasks:

Export:

- Builds DICOM Information Objects.
- Creates a DICOMDIR file that represents the contents of the DICOM Information Objects to be recorded.
- Records DICOM Information Objects and the DICOMDIR file to the CD-R or the DVD+R medium.

Import:

- Reads the DICOMDIR file that represents the contents of the data as recorded.
- Displays the ordered list of studies/series/images, identifying information.
- Loads the selected studies/series/images from the CD-R or the DVD+R medium and displays them on the screen.

Note: The Offline-Media AE can update files created by the product itself.

5.1.3 Sequencing of Real-World Activities

5.1.3.1 Activity – Export Image Files

Operator requests to create new File-set(s) onto a new CD-R or DVD+R. The requests are placed in a queue and are executed in the background.

The operations for “Export Image Files” are described below:

- Step-1: Select the studies on the local storage device to be created to the CD-R or the DVD+R medium.
- Step-2: Select the image archiving.
- Step-3: Select the virtual device as a destination.
- Step-4: Request to copy to the CD-R or the DVD+R.

5.1.3.2 Activity – Import Image Files

Operator requests to retrieve File-set(s) on the CD-R or the DVD+R. The requests are placed in a queue and are executed in the background.

The operations for “Import Image Files” are described below:

- Step-1: Select the studies on the medium to be retrieved to the local storage device.
- Step-2: Select the data retrieval.
- Step-3: Request to copy to the local storage device.

5.1.4 File Meta Information for Implementation Class and Version

The implementation information written to the File Meta Header in each file is:

**Table 5.1-1
DICOM IMPLEMENTATION CLASS AND VERSION FOR MEDIA STORAGE**

File Meta Information Version	1
Implementation Class UID	2.16.124.113531.1.1
Implementation Version Name	Cedara RMA v3.0

5.2 AE SPECIFICATIONS

5.2.1 Offline-Media AE Specification

The Offline-Media AE provides standard conformance to the DICOM Interchange Option of the Media Storage Service Class. The Application Profiles and roles are listed below:

**Table 5.2-1
APPLICATION PROFILES, ACTIVITIES AND ROLES FOR OFFLINE-MEDIA**

Application Profiles Supported	Real World Activity	Role	SC Option
AUG-US-ID-MF-CD, AUG-US-ID-MF-DVD	Export Image Files	FSC	Interchange
	Import Image Files	FSR	Interchange

5.2.1.1 File Meta Information for the Application Entity

The Source Application Entity Title is the same as the Local AE Title.

5.2.1.2 Real-World Activities

5.2.1.2.1 Activity – Export Image Files

The Offline-Media AE acts as an FSC using the interchange option when requested to export SOP Instances from the local database to a CD-R or a DVD+R medium.

5.2.1.2.2 Activity – Import Image Files

The Offline-Media AE acts as an FSR using the interchange option when requested to import SOP Instances from a CD-R or a DVD+R medium to the local database.

5.3 AUGMENTED AND PRIVATE APPLICATION PROFILES

5.3.1 Augmented Application Profiles

Not applicable to this product.

5.3.1.1 Augmented Application Profiles – AUG-US-ID-MF-CD & AUG-US-ID-MF-DVD

5.3.1.1.1 SOP Class Augmentations

The Augmented Application Profile supports the following SOP Classes and Transfer Syntaxes.

Table 5.3-1
SOP Class Augmentations

Information Object Definition	SOP Class UID	Transfer Syntax	Transfer Syntax UID
DICOM Media Storage Directory	1.2.840.10008.1.3.10	Explicit VR LittleEndian	1.2.840.10008.1.2.1
Ultrasound Image Storage	1.2.840.10008.5.1.4.1.1.6.1	Implicit VR LittleEndian	1.2.840.10008.1.2
		Explicit VR LittleEndian	1.2.840.10008.1.2.1
		RLE Lossless	1.2.840.10008.1.2.5
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50
Ultrasound Multi-frame Image Storage	1.2.840.10008.5.1.4.1.1.3.1	Implicit VR LittleEndian	1.2.840.10008.1.2
		Explicit VR LittleEndian	1.2.840.10008.1.2.1
		RLE Lossless	1.2.840.10008.1.2.5
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50
Secondary Capture Image Storage	1.2.840.10008.5.1.4.1.1.7	Implicit VR LittleEndian	1.2.840.10008.1.2
		Explicit VR LittleEndian	1.2.840.10008.1.2.1
		RLE Lossless	1.2.840.10008.1.2.5
		JPEG Baseline (Process 1)	1.2.840.10008.1.2.4.50
Enhanced SR Storage	1.2.840.10008.5.1.4.1.1.88.22	Implicit VR LittleEndian	1.2.840.10008.1.2
		Explicit VR LittleEndian	1.2.840.10008.1.2.1

5.3.1.1.2 Directory Augmentations

Not applicable to this product.

5.3.1.1.3 Other Augmentations

Not applicable to this product.

5.3.2 Private Application Profiles

Not applicable to this product.

5.4 MEDIA CONFIGURATION

Not applicable to the Offline-Media AE.

6. SUPPORT OF CHARACTER SETS

This product supports ISO-IR 100 (Latin alphabet No.1) Supplementary set of ISO8859.

7. SECURTIY

This product does not support any specific security measures.

It is assumed that the product is used within a secured environment. It is assumed that a secured environment includes at a minimum:

- a. Firewall or router protections to ensure that only approved external hosts have network access to the product.
- b. Firewall or router protections to ensure that the product only has network access to approved external hosts and services.

Other network security procedures such as automated intrusion detection may be appropriate in some environments. Additional security features may be established by the local security policy and are beyond the scope of this conformance statement.

8. ANNEXES

8.1 IOD CONTENTS

8.1.1 Created SOP Instances

Table 8.1-1 specifies the attributes of a Secondary Capture Image transmitted by the Storage SCU AE.

Table 8.1-2 specifies the attributes of an Ultrasound Image transmitted by the Storage SCU AE.

Table 8.1-3 specifies the attributes of an Ultrasound Multi-frame Image transmitted by the Storage SCU AE.

Table 8.1-4 specifies the attributes of an Enhanced SR transmitted by the Storage SCU AE.

The following tables use a number of abbreviations. The abbreviations used in the “Presence of ...” column are:

VNAP	Value Not Always Present (attribute sent zero length if no value is present)
ANAP	Attribute Not Always Present
ALWAYS	Always Present
EMPTY	Attribute is sent without a value

The abbreviations used in the “Source” column:

MWL	the attribute value source Modality Worklist
USER	the attribute value source is from user input
AUTO	the attribute value is generated automatically
MPPS	the attribute value is the same as that use for Modality Performed Procedure Step
CONFIG	the attribute value source is a configurable parameter

8.1.1.1 SC Image IOD

**Table 8.1-1
IOD OF CREATED SC IMAGE SOP INSTANCES**

IE	Module	Reference	Presence of Module
Patient	Patient	Table 8.1-5	ALWAYS
	Clinical Trial Subject	--	Not Present
Study	General Study	Table 8.1-6	ALWAYS
	Patient Study	Table 8.1-7	ALWAYS
	Clinical Trial Study	--	Not Present
Series	General Series	Table 8.1-8	ALWAYS
	Clinical Trial Series	--	Not Present
Equipment	General Equipment	Table 8.1-9	ALWAYS
	SC Equipment	--	Not Present
Image	General Image	Table 8.1-10	ALWAYS
	Image Pixel	Table 8.1-11	ALWAYS
	SC Image	--	Not Present
	Overlay Plane	--	Not Present
	Modality LUT	--	Not Present
	VOI LUT	--	Not Present
	SOP Common	Table 8.1-16	ALWAYS

8.1.1.2 US Image IOD

**Table 8.1-2
IOD OF CREATED US IMAGE SOP INSTANCES**

IE	Module	Reference	Presence of Module
Patient	Patient	Table 8.1-5	ALWAYS
	Clinical Trial Subject	--	Not Present
Study	General Study	Table 8.1-6	ALWAYS
	Patient Study	Table 8.1-7	ALWAYS
	Clinical Trial Study	--	Not Present
Series	General Series	Table 8.1-8	ALWAYS
	Clinical Trial Series	--	Not Present
Frame of Reference	Frame of Reference	--	Not Present
	Synchronization	--	Not Present
Equipment	General Equipment	Table 8.1-9	ALWAYS
Image	General Image	Table 8.1-10	ALWAYS
	Image Pixel	Table 8.1-11	ALWAYS
	Contrast/bolus	--	Not Present
	Palette Color Lookup Table	--	Not Present
	US Region Calibration	Table 8.1-12-15	ALWAYS
	US Image	Table 8.1-17	ALWAYS
	Overlay Plane	--	Not Present
	VOI LUT	--	Not Present
	SOP Common	Table 8.1-18	ALWAYS

8.1.1.3 US Multi-frame Image IOD

**Table 8.1-3
IOD OF CREATED US MULTI-FRAME IMAGE SOP INSTANCES**

IE	Module	Reference	Presence of Module
Patient	Patient	Table 8.1-5	ALWAYS
	Clinical Trial Subject	--	Not Present
Study	General Study	Table 8.1-6	ALWAYS
	Patient Study	Table 8.1-7	ALWAYS
	Clinical Trial Study	--	Not Present
Series	General Series	Table 8.1-8	ALWAYS
	Clinical Trial Series	--	Not Present
Frame of Reference	Frame of Reference	--	Not Present
	Synchronization	--	Not Present
Equipment	General Equipment	Table 8.1-9	ALWAYS
Image	General Image	Table 8.1-10	ALWAYS
	Image Pixel	Table 8.1-11	ALWAYS
	Contrast/bolus	--	Not Present
	Cine	Table 8.1-19	ALWAYS
	Multi-frame	Table 8.1-20	ALWAYS
	Frame Pointers	--	Not Present
	Palette Color Lookup Table	--	Not Present
	US Region Calibration	Table 8.1-12-15	ALWAYS
	US Image	Table 8.1-21	ALWAYS
	VOI LUT	--	Not Present
	SOP Common	Table 8.1-22	ALWAYS

8.1.1.4 Enhanced SR IOD

**Table 8.1-4
IOD OF CREATED ENHANCED SR SOP INSTANCES**

IE	Module	Reference	Presence of Module
Patient	Patient	Table 8.1-5	ALWAYS
	Specimen Identification	--	Not Present
	Clinical Trial Subject	--	Not Present
Study	General Study	Table 8.1-6	ALWAYS
	Patient Study	Table 8.1-7	ALWAYS
	Clinical Trial Study	--	Not Present
Series	SR Document Series	Table 8.1-23	ALWAYS
	Clinical Trial Series	--	Not Present
Equipment	General Equipment	Table 8.1-9	ALWAYS
Document	SR Document General	Table 8.1-24	ALWAYS
	SR Document Content	Table 8.1-26-56	ALWAYS, ONLY ONE ACCORDING TO THE TEMPLATE USED
	SOP Common	Table 8.1-25	ALWAYS

8.1.1.5 Common Modules

**Table 8.1-5
PATIENT MODULE OF CREATED SOP INSTANCES**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Patient's Name	(0010,0010)	PN		ALWAYS	MWL/USER
Patient ID	(0010,0020)	LO		ALWAYS	MWL/USER
Patient's Birth Date	(0010,0030)	DA		VNAP	MWL/USER
Patient's Sex	(0010,0040)	CS		VNAP	MWL/USER
Referenced Patient Sequence	(0008,1120)	SQ		ANAP	MWL
>Referenced SOP Class UID	(0008,1150)	UI		ANAP	MWL
>Referenced SOP Instance UID	(0008,1155)	UI		ANAP	MWL
Ethnic Group	(0010,2160)	SH		ANAP	USER
Patient Comments	(0010,4000)	LT		ANAP	USER

**Table 8.1-6
GENERAL STUDY MODULE OF CREATED SOP INSTANCES**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Study Instance UID	(0020,000D)	UI		ALWAYS	MWL/AUTO
Study Date	(0008,0020)	DA		ALWAYS	AUTO
Study Time	(0008,0030)	TM		ALWAYS	AUTO
Referring Physician's Name	(0008,0090)	PN		VNAP	MWL/USER
Study ID	(0020,0010)	SH		ALWAYS	AUTO
Accession Number	(0008,0050)	SH		VNAP	MWL/USER
Study Description	(0008,1030)	LO		ANAP	USER
Name of Physician(s) Reading Study	(0008,1060)	PN		ANAP	USER
Referenced Study Sequence	(0008,1110)	SQ		ANAP	MWL
>Referenced SOP Class UID	(0008,1150)	UI		ANAP	MWL
>Referenced SOP Instance UID	(0008,1155)	UI		ANAP	MWL

**Table 8.1-7
PATIENT STUDY MODULE OF CREATED SOP INSTANCES**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Patient's Age	(0008,1010)	AS		ANAP	AUTO
Patient's Size	(0010,1020)	DS		ANAP	USER
Patient's Weight	(0010,1030)	DS		ANAP	USER

Table 8.1-8
GENERAL SERIES MODULE OF CREATED SOP INSTANCES

Attribute Name	Tag	VR	Value	Presence of Value	Source
Modality	(0008,0060)	CS	US	ALWAYS	AUTO
Series Instance UID	(0020,000E)	UI		ALWAYS	AUTO
Series Number	(0020,0011)	IS		ALWAYS	AUTO
Series Date	(0008,0021)	DA		ANAP	AUTO
Series Time	(0008,0031)	TM		ANAP	AUTO
Protocol Name	(0018,1030)	LO		ANAP	AUTO
Operator's Name	(0008,1070)	PN		ANAP	USER
Referenced Performed Procedure Step Sequence	(0008,1111)	SQ		VNAP	AUTO
>Referenced SOP Class UID	(0008,1150)	UI		VNAP	AUTO
>Referenced SOP Instance UID	(0008,1155)	UI		VNAP	AUTO
Request Attributes Sequence	(0040,0275)	SQ		ANAP	AUTO
>Requested Procedure ID	(0040,1001)	SH		ANAP	MWL
>Scheduled Procedure Step ID	(0040,0009)	SH		ANAP	MWL
>Scheduled Procedure Step Description	(0040,0007)	LO		ANAP	MWL
>Scheduled Protocol Code Sequence	(0040,0008)	SQ		ANAP	MWL
>>Code Value	(0008,0100)	SH		ANAP	MWL
>>Coding Scheme Designator	(0008,0102)	SH		ANAP	MWL
>>Code Meaning	(0008,0104)	LO		ANAP	MWL
Performed Procedure Step ID	(0040,0253)	SH		ANAP	AUTO
Performed Procedure Step Start Date	(0040,0244)	DA		ANAP	AUTO
Performed Procedure Step Start Time	(0040,0245)	TM		ANAP	AUTO
Performed Procedure Step Description	(0040,0254)	LO		ANAP	AUTO

Table 8.1-9
GENERAL EQUIPMENT MODULE OF CREATED SOP INSTANCES

Attribute Name	Tag	VR	Value	Presence of Value	Source
Manufacturer	(0008,0070)	LO	TOSHIBA_MEC	ALWAYS	AUTO
Institution Name	(0008,0080)	LO		ANAP	CONFIG
Station Name	(0008,1010)	LO		ANAP	CONFIG
Institutional Department Name	(0008,1040)	LO		ANAP	USER
Manufacturer's Model Name	(0008,1090)	LO	SSA-580A	ALWAYS	AUTO
Device Serial Number	(0018,1000)	LO		ALWAYS	AUTO
Software Version	(0018,1020)	LO	0.7.390	ALWAYS	AUTO

Table 8.1-10
GENERAL IMAGE MODULE OF CREATED SOP INSTANCES

Attribute Name	Tag	VR	Value	Presence of Value	Source
Instance Number	(0020,0013)	IS		ALWAYS	AUTO
Patient Orientation	(0020,0020)	CS		EMPTY	AUTO
Content Date	(0008,0023)	DA		ALWAYS	AUTO
Content Time	(0008,0033)	TM		ALWAYS	AUTO
Image Type	(0008,0008)	CS		ANAP	AUTO
Image Comments	(0020,4000)	LT		ALWAYS	AUTO
Lossy Image Compression	(0028,2110)	CS		ANAP	AUTO

Table 8.1-11
IMAGE PIXEL MODULE OF CREATED SOP INSTANCES

Attribute Name	Tag	VR	Value	Presence of Value	Source
Samples per Pixel	(0028,0002)	US	3 or 1	ALWAYS	AUTO
Photometric Interpretation	(0028,0004)	CS	“RGB”, “YBR_FULL422”, or “MONOCHROME2” Note: if “MONOCHROME2”, then - (0028,0002) 1 - (0028,0006) Not Present	ALWAYS	CONFIG
Rows	(0028,0010)	US	480	ALWAYS	AUTO
Columns	(0028,0011)	US	640	ALWAYS	AUTO
Bits Allocated	(0028,0100)	US	8	ALWAYS	AUTO
Bits Stored	(0028,0101)	US	8	ALWAYS	AUTO
High Bit	(0028,0102)	US	7	ALWAYS	AUTO
Pixel Representation	(0028,0103)	US	0	ALWAYS	AUTO
Pixel Data	(7FE0,0010)	OB or OW		ALWAYS	AUTO
Planar Configuration	(0028,0006)	US	0 or 1	ANAP	AUTO

8.1.1.6 US Region Calibration Module

**Table 8.1-12
US REGION CALIBRATION MODULE B-MODE**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Sequence of Ultrasound Regions	(0018,6011)	SQ		ALWAYS	AUTO
>Region Spatial Format	(0018,6012)	US	1	ALWAYS	AUTO
>Region Data Type	(0018,6014)	US	1	ALWAYS	AUTO
>Region Flags	(0018,6016)	UL		ALWAYS	AUTO
>Region Location Min x0	(0018,6018)	UL		ALWAYS	AUTO
>Region Location Min y0	(0018,601A)	UL		ALWAYS	AUTO
>Region Location Max x1	(0018,601C)	UL		ALWAYS	AUTO
>Region Location Max y1	(0018,601E)	UL		ALWAYS	AUTO
>Reference Pixel x0	(0018,6020)	SL		ALWAYS	AUTO
>Reference Pixel y0	(0018,6022)	SL		ALWAYS	AUTO
>Physical Units X Direction	(0018,6024)	US		ALWAYS	AUTO
>Physical Units Y Direction	(0018,6026)	US		ALWAYS	AUTO
>Reference Pixel Physical Value X	(0018,6028)	FD		ALWAYS	AUTO
>Reference Pixel Physical Value Y	(0018,602A)	FD		ALWAYS	AUTO
>Physical Delta X	(0018,602C)	FD		ALWAYS	AUTO
>Physical Delta Y	(0018,602E)	FD		ALWAYS	AUTO
>Transducer Frequency	(0018,6030)	UL		ALWAYS	AUTO
>Steering Angle	(0018,6036)	FD		ANAP	AUTO

Table 8.1-13
US REGION CALIBRATION MODULE BC-MODE

Attribute Name	Tag	VR	Value	Presence of Value	Source
Sequence of Ultrasound Regions	(0018,6011)	SQ		ALWAYS	AUTO
>Region Spatial Format	(0018,6012)	US	1	ALWAYS	AUTO
>Region Data Type	(0018,6014)	US	2	ALWAYS	AUTO
>Region Flags	(0018,6016)	UL		ALWAYS	AUTO
>Region Location Min x0	(0018,6018)	UL		ALWAYS	AUTO
>Region Location Min y0	(0018,601A)	UL		ALWAYS	AUTO
>Region Location Max x1	(0018,601C)	UL		ALWAYS	AUTO
>Region Location Max y1	(0018,601E)	UL		ALWAYS	AUTO
>Reference Pixel x0	(0018,6020)	SL		ALWAYS	AUTO
>Reference Pixel y0	(0018,6022)	SL		ALWAYS	AUTO
>Physical Units X Direction	(0018,6024)	US		ALWAYS	AUTO
>Physical Units Y Direction	(0018,6026)	US		ALWAYS	AUTO
>Reference Pixel Physical Value X	(0018,6028)	FD		ALWAYS	AUTO
>Reference Pixel Physical Value Y	(0018,602A)	FD		ALWAYS	AUTO
>Physical Delta X	(0018,602C)	FD		ALWAYS	AUTO
>Physical Delta Y	(0018,602E)	FD		ALWAYS	AUTO
>Transducer Frequency	(0018,6030)	UL		ALWAYS	AUTO
>Pulse Repetition Frequency	(0018,6032)	UL		ALWAYS	AUTO
>Steering Angle	(0018,6036)	FD		ANAP	AUTO

Table 8.1-14
US REGION CALIBRATION MODULE D-MODE

Attribute Name	Tag	VR	Value	Presence of Value	Source
Sequence of Ultrasound Regions	(0018,6011)	SQ		ALWAYS	AUTO
>Region Spatial Format	(0018,6012)	US	3	ALWAYS	AUTO
>Region Data Type	(0018,6014)	US	3 or 4	ALWAYS	USER
>Region Flags	(0018,6016)	UL		ALWAYS	AUTO
>Region Location Min x0	(0018,6018)	UL		ALWAYS	AUTO
>Region Location Min y0	(0018,601A)	UL		ALWAYS	AUTO
>Region Location Max x1	(0018,601C)	UL		ALWAYS	AUTO
>Region Location Max y1	(0018,601E)	UL		ALWAYS	AUTO
>Reference Pixel x0	(0018,6020)	SL		ALWAYS	AUTO
>Reference Pixel y0	(0018,6022)	SL		ALWAYS	AUTO
>Physical Units X Direction	(0018,6024)	US		ALWAYS	AUTO
>Physical Units Y Direction	(0018,6026)	US		ALWAYS	AUTO
>Reference Pixel Physical Value X	(0018,6028)	FD		ALWAYS	AUTO
>Reference Pixel Physical Value Y	(0018,602A)	FD		ALWAYS	AUTO
>Physical Delta X	(0018,602C)	FD		ALWAYS	AUTO
>Physical Delta Y	(0018,602E)	FD		ALWAYS	AUTO
>Transducer Frequency	(0018,6030)	UL		ALWAYS	AUTO
>Pulse Repetition Frequency	(0018,6032)	UL		ALWAYS	AUTO
>Doppler Correction Angle	(0018,6034)	FD		ALWAYS	AUTO
>Steering Angle	(0018,6036)	FD		ALWAYS	AUTO
>Doppler Sample Volume X Position	(0018,6038)	UL		ALWAYS	AUTO
>Doppler Sample Volume Y Position	(0018,603A)	UL		ALWAYS	AUTO
>TM-Line Position x0	(0018,603C)	UL		ALWAYS	AUTO
>TM-Line Position y0	(0018,603E)	UL		ALWAYS	AUTO
>TM-Line Position x1	(0018,6040)	UL		ALWAYS	AUTO
>TM-Line Position y1	(0018,6042)	UL		ALWAYS	AUTO

Table 8.1-15
US REGION CALIBRATION MODULE M-MODE

Attribute Name	Tag	VR	Value	Presence of Value	Source
Sequence of Ultrasound Regions	(0018,6011)	SQ		ALWAYS	AUTO
>Region Spatial Format	(0018,6012)	US	2	ALWAYS	AUTO
>Region Data Type	(0018,6014)	US	1	ALWAYS	AUTO
>Region Flags	(0018,6016)	UL		ALWAYS	AUTO
>Region Location Min x0	(0018,6018)	UL		ALWAYS	AUTO
>Region Location Min y0	(0018,601A)	UL		ALWAYS	AUTO
>Region Location Max x1	(0018,601C)	UL		ALWAYS	AUTO
>Region Location Max y1	(0018,601E)	UL		ALWAYS	AUTO
>Reference Pixel x0	(0018,6020)	SL		ALWAYS	AUTO
>Reference Pixel y0	(0018,6022)	SL		ALWAYS	AUTO
>Physical Units X Direction	(0018,6024)	US		ALWAYS	AUTO
>Physical Units Y Direction	(0018,6026)	US		ALWAYS	AUTO
>Reference Pixel Physical Value X	(0018,6028)	FD		ALWAYS	AUTO
>Reference Pixel Physical Value Y	(0018,602A)	FD		ALWAYS	AUTO
>Physical Delta X	(0018,602C)	FD		ALWAYS	AUTO
>Physical Delta Y	(0018,602E)	FD		ALWAYS	AUTO
>Transducer Frequency	(0018,6030)	UL		ALWAYS	AUTO
>TM-Line Position x0	(0018,603C)	UL		ALWAYS	AUTO
>TM-Line Position y0	(0018,603E)	UL		ALWAYS	AUTO
>TM-Line Position x1	(0018,6040)	UL		ALWAYS	AUTO
>TM-Line Position y1	(0018,6042)	UL		ALWAYS	AUTO

8.1.1.7 SC Image Modules

Table 8.1-16
SOP COMMON MODULE OF CREATED SC IMAGE INSTANCES

Attribute Name	Tag	VR	Value	Presence of Value	Source
Specific Character Set	(0008,0008)	CS	ISO_IR 100	ALWAYS	AUTO
SOP Class UID	(0008,0016)	UI	1.2.840.10008.5.1.4.1.1.7	ALWAYS	AUTO
SOP Instance UID	(0008,0018)	UI		ALWAYS	AUTO

8.1.1.8 US Image Modules

Table 8.1-17
US IMAGE MODULE OF CREATED US IMAGE SOP INSTANCES

Attribute Name	Tag	VR	Value	Presence of Value	Source
Samples per Pixel	(0028,0002)	US	3 or 1	ALWAYS	AUTO
Photometric Interpretation	(0028,0004)	CS	“RGB”, “YBR_FULL422”, or “MONOCHROME2” Note: if “MONOCHROME2”, then - (0028,0002) 1 - (0028,0006) Not Present - (0028,0014) 0	ALWAYS	CONFIG
Bits Allocated	(0028,0100)	US	8	ALWAYS	AUTO
Bits Stored	(0028,0101)	US	8	ALWAYS	AUTO
High Bit	(0028,0102)	US	7	ALWAYS	AUTO
Planar Configuration	(0028,0006)	US	0 or 1	ANAP	AUTO
Pixel Representation	(0028,0103)	US	0	ALWAYS	AUTO
Image Type	(0008,0008)	CS		EMPTY	AUTO
Lossy Image Compression	(0028,2110)	CS		ANAP	AUTO
Pixel Data	(7FE0,0010)	OB or OW		ALWAYS	AUTO
Ultrasound Color Data Present	(0028,0014)	US	1 or 0	ALWAYS	AUTO
Transducer Type	(0018,6031)	CS		ALWAYS	AUTO

Table 8.1-18
SOP COMMON MODULE OF CREATED US IMAGE SOP INSTANCES

Attribute Name	Tag	VR	Value	Presence of Value	Source
Specific Character Set	(0008,0008)	CS	ISO_IR 100	ALWAYS	AUTO
SOP Class UID	(0008,0016)	UI	1.2.840.10008.5.1.4.1.1.6.1	ALWAYS	AUTO
SOP Instance UID	(0008,0018)	UI		ALWAYS	AUTO

8.1.1.9 US Multi-frame Image Modules

**Table 8.1-19
CINE MODULE OF CREATED US MULTI-FRAME IMAGE SOP INSTANCES**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Frame Time	(0018,1063)	DS		ALWAYS	AUTO
Start Trim	(0008,2142)	IS		ALWAYS	AUTO
Stop Trim	(0008,2143)	IS		ALWAYS	AUTO
Recommended Display Frame Rate	(0008,2144)	IS		ALWAYS	CONFIG
Cine Rate	(0018,0040)	IS		ALWAYS	CONFIG
Frame Delay	(0018,1066)	DS		ALWAYS	AUTO
Effective Duration	(0018,0072)	DS		ALWAYS	AUTO
Actual Frame Duration	(0018,1242)	IS		ALWAYS	AUTO

**Table 8.1-20
MULTI-FRAME MODULE OF CREATED US MULTI-FRAME IMAGE SOP INSTANCES**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Number of Frames	(0028,0008)	IS		ALWAYS	USER
Frame Increment Pointer	(0028,0009)	AT		ALWAYS	AUTO

**Table 8.1-21
US IMAGE MODULE OF CREATED US MULTI-FRAME IMAGE SOP INSTANCES**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Samples per Pixel	(0028,0002)	US	3	ALWAYS	AUTO
Photometric Interpretation	(0028,0004)	CS	RGB or YBR_FULL422	ALWAYS	AUTO
Bits Allocated	(0028,0100)	US	8	ALWAYS	AUTO
Bits Stored	(0028,0101)	US	8	ALWAYS	AUTO
High Bit	(0028,0102)	US	7	ALWAYS	AUTO
Planar Configuration	(0028,0006)	US	0	ALWAYS	AUTO
Pixel Representation	(0028,0103)	US	0	ALWAYS	AUTO
Frame Increment Pointer	(0028,0009)	AT		ALWAYS	AUTO
Image Type	(0008,0008)	CS		EMPTY	AUTO
Lossy Image Compression	(0028,2110)	CS		ANAP	AUTO
Number of Stages	(0008,2124)	IS		ANAP	AUTO
Number of Views in Stage	(0008,212A)	IS		ANAP	AUTO
Ultrasound Color Data Present	(0028,0014)	US	1	ALWAYS	AUTO
Stage Name	(0008,2120)	SH		ANAP	AUTO
Stage Number	(0008,2122)	IS		ANAP	AUTO
View Name	(0008,2127)	SH		ANAP	AUTO
View Number	(0008,2128)	IS		ANAP	AUTO
Heart Rate	(0008,1088)	IS		ANAP	AUTO
Transducer Type	(0018,6031)	CS		ALWAYS	AUTO

Table 8.1-22
SOP COMMON MODULE OF CREATED US MULTI-FRAME IMAGE SOP INSTANCES

Attribute Name	Tag	VR	Value	Presence of Value	Source
Specific Character Set	(0008,0008)	CS	ISO_IR 100	ALWAYS	AUTO
SOP Class UID	(0008,0016)	UI	1.2.840.10008.5.1.4.1.1.3.1	ALWAYS	AUTO
SOP Instance UID	(0008,0018)	UI		ALWAYS	AUTO

8.1.1.10 Enhanced SR Modules

Table 8.1-23
SR DOCUMENT SERIES MODULE OF CREATED ENHANCED SR SOP INSTANCES

Attribute Name	Tag	VR	Value	Presence of Value	Source
Modality	(0008,0060)	CS	SR	ALWAYS	AUTO
Series Instance UID	(0020,000E)	UI		ALWAYS	AUTO
Series Number	(0020,0011)	IS		ALWAYS	AUTO
Referenced Performed Procedure Step Sequence	(0008,1111)	SQ		VNAP	AUTO
>Referenced SOP Class UID	(0008,1150)	UI		ANAP	AUTO
>Referenced SOP Instance UID	(0008,1155)	UI		ANAP	AUTO

Table 8.1-24
SR DOCUMENT GENERAL MODULE OF CREATED ENHANCED SR SOP INSTANCES

Attribute Name	Tag	VR	Value	Presence of Value	Source
Instance Number	(0020,0013)	IS		ALWAYS	AUTO
Completion Flag	(0040,A491)	CS	COMPLETE	ALWAYS	AUTO
Verification Flag	(0040,A493)	CS	UNVERIFIED	ALWAYS	AUTO
Content Date	(0008,0023)	DA		ALWAYS	AUTO
Content Time	(0008,0033)	TM		ALWAYS	AUTO

Table 8.1-25
SOP COMMON MODULE OF CREATED ENHANCED SR SOP INSTANCES

Attribute Name	Tag	VR	Value	Presence of Value	Source
Specific Character Set	(0008,0008)	CS	ISO_IR 100	ALWAYS	AUTO
SOP Class UID	(0008,0016)	UI	1.2.840.10008.5.1.4.1.1.88.22	ALWAYS	AUTO
SOP Instance UID	(0008,0018)	UI		ALWAYS	AUTO

8.1.1.10.1 Nemio XG Unit Measurement

Table 8.1-26
AORTIC VALVE Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO

>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02350003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	RVOTD: Diameter of the right ventricular outflow tract	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02350004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AOD: Diameter of the aorta	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02350005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	LAD: Diameter of the left atrium	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02350006	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	AVD: Diameter of the aortic valve	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02350007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	ET: Ejection Time	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millisecond	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02350009	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	LA/AO	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT	00000.98	ALWAYS	AUTO

Table 8.1-27
TRICUSPED VALVE Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO

>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12. 100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO

>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025B0003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	TV VTI: Tricuspid valve VTI	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025B0005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	TV VP: Tricuspid valve maximum velocity	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025B0006	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	TV MPG: Tricuspid valve mean pressure gradient	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025B0007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	TV PPG: Tricuspid valve maximum pressure gradien	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025B0010	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	TV Vel: Tricuspid valve velocity	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025B0011	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	TV PG: Tricuspid valve maximum pressure gradient	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-28
LV SIMPSON'S BIPLANE Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO

>Concept Name Code Sequence	(0040,A043)	SH		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SH		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	BPL	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02130003	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	L(D)4: Length of the end-diastolic four-chamber long axis cross-sectional left ventricle	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02130005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	L(S)4: Area of the end-diastolic four-chamber long-axis cross-sectional left ventricle	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02130004	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	A(D)4: Area of the end-diastolic four-chamber long-axis cross-sectional left ventricle	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02130006	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	A(S)4: Area of the end-systole two-chamber long-axis cross-sectional left ventricle	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02130024	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SI4: SI obtained from the measurement results for the four-chamber cross-sectional LV images	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mL/m ²	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02130025	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	CI4: CO index4	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02130027	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	L(D)2: Length of the end-diastolic two-chamber long axis cross-sectional left ventricle	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02130008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	A(D)2	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-29
LV SIMPSON'S SINGLE PLANE Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO

>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02110003	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	L(D): Length of the long-axis end-diastolic left ventricle	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02110006	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	L(S): Length of the long-axis end-systolic left ventricle	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02110004	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	A(D): Area of the long-axis ends-diastolic left ventricle	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	square centimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02110007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	A(S): Area of the long-axis ends-systolic left ventricle	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	square centimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02110009	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	HR: Heart rate	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	bpm	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02110008	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	ESV: End-systolic left ventricular volume	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	ML	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0211000B	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	SV: Stork volume	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	ML	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-30
LV CUBE Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO

>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12. 100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02030003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	IVSTd: Sepals thickness of the ventricle in end diastole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02030004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	LVIDd: Diameter of the short-axis left ventricle in end diastole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO

>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02030005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	LVPWd: Thickness of the posterior wall of the left ventricle in end diastole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02030006	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	IVSTs: Thickness of the ventricular septum within the tracing interval	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02030007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	LVIDs: Diameter of the short-axis left ventricle in end systole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02030008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	LVPWs: Thickness of the posterior wall of the left ventricle in end systole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0203000A	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	HR: Heart rate	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	bpm	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0203000B	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	EDV: Volume of the end-diastolic left ventricle	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	ML		
>>Numeric Value	(0040, 30A)	DS			

Table 8.1-31
LV GIBSON Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO

>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO

>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02070003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	IVSTd: Sepal thickness of the ventricle in end diastole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02070004	ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	LVIDd: Diameter of the short-axis left ventricle in end diastole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02070005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	LVPWd: Thickness of the posterior wall of the left ventricle in end diastole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02070006	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	IVSTs: Sepal thickness of the ventricle end systole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02070007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	LVIDs: Diameter of the short-axis left ventricle in end systole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO

>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02070008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	LVPWs: Thickness of the posterior wall of the left ventricle in end systole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02070009	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	ET	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millisecond	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0207000A	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HR: Heart rate	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	bpm		
>>>Numeric Value	(0040,A30A)	DS			

Table 8.1-32
LV BULLET Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO

>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	020D0004	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	LVAMD: Area of the long-axis left ventricle at the level of the mitral in end diastole	ALWAYS	AUTO

>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square centimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	020D0003	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	LVLd: Length of the long-axis left ventricle in end diastole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	020D0006	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	LVAMs: Area of the short-axis left ventricle at the level of the mitral valve in end systole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square centimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	020D0005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	LVLs: Length of the long-axis left ventricle at end systole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO

>>>Code Value	(0008,0100)	SH	020D0007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HR	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	bpm	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	020D0009	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	EDV: EDV= 5/6xLVLDxLVAMD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	ML	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	020D000A	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	ESV	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	ML	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	020D000B	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SV	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	ML		
>>>Numeric Value	(0040,A30A)	DS			

Table 8.1-33
LV SIMPSON Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	020F0003	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	LVLD: Left ventricular long-axis area at the Level of the mitral valve at end diastole	ALWAYS	AUTO
>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	020F0004	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	LVAMD: Left ventricular short-axis area at the Level of the mitral valve at end diastole	ALWAYS	AUTO
>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	square centimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	020F0005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	LVAPD: Area of the long-axis left ventricle at level of the papillary in end diastole	ALWAYS	AUTO
>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	square centimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO

>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	020F0006	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	LVLS: Length of the long-axis left ventricle in end systole	ALWAYS	AUTO
>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	020F0007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	LVAMs: Area of the short-axis left ventricle at the papilla muscle in end systole	ALWAYS	AUTO
>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	square centimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	020F0008	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	LVAPs: Area of the short-axis left ventricle in end of the systole	ALWAYS	AUTO
>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	square centimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	020F0009	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	HR: Heart rate	ALWAYS	AUTO
>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	bpm	ALWAYS	AUTO

>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	020F000B	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	EDV: Volume of the left ventricle in end diastole	ALWAYS	AUTO
>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	ML		
>>Numeric Value	(0040,A30A)	DS			

Table 8.1-34
LV TEICHHOLZ Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO

>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02050003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	IVSTd: Sepal thickness of the ventricle in end diastole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02050004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	LVIDd: Diameter of the short-axis left ventricle in end diastole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02050005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	LVPWd: Thickness of the posterior wall of the left ventricle in end diastole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02050006	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	IVSTs: Sepal thickness of the ventricle end systole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02050007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	LVIDs: Diameter of the short-axis left ventricle in end systole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02050008	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	LVPWs: Thickness of the posterior wall of the left ventricle in end systole	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO

>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0205000A	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HR: Heart Rate	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	bpm	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0205000B	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	EDV: 7xLVIDd3/2.4 +LVIDd	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	ML		
>>>Numeric Value	(0040,A30A)	DS			

Table 8.1-35
LV BIPLANE ELLIPSE Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
ValueType	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>CodeValue	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>CodingSchemeDesignator	(0008,0102)	SH	LN	ALWAYS	AUTO
>CodeMeaning	(0008,0104)	LO	RadiologyReport	ALWAYS	AUTO
ContinuityofContent	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
ContentTemplateSequence	(0040,A504)	SQ		ALWAYS	AUTO
>MappingResource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>TemplateIdentifier	(0040,DB00)	CS		ALWAYS	AUTO
ContentSequence	(0040,A730)	SQ		ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	HASCONCEPTMOD	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	CODE	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121049	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	LanguageofContentItemand Descendents	ALWAYS	AUTO
>ConceptCodeSequence	(0040,A168)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	en	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	English	ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	HASOBSCONTEXT	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	CODE	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121005	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO

>>CodeMeaning	(0008,0104)	LO	ObservationType	ALWAYS	AUTO
>ConceptCodeSequence	(0040,A168)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121007	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	HASOBSCONTEXT	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121012	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	DeviceObserverUID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121070	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>ContinuityofContent	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>ContentSequence	(0040,A730)	SQ		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>ValueType	(0040,A040)	CS	NUM	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	squaremeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	BPH	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	BPL	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	SH	mmHg	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	020B0003	ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	LVALd:Areaofthelong-axisle ftventricleinenddiastole	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	squarecentimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	020B0004	ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	LVAMd	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO

>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	squarecentimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	020B0005	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	LVIDd	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	020B0006	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	LVALs:Areaofthelong-axisle ftventricleinendsystole	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	squarecentimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	020B0007	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	LVAMs	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	squarecentimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	020B0008	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	LVIDs	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO

>>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	020B0009	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	HR:Heartrate	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	bpm	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	020B000B	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	EDV:Volumeoftheleftventricleinenddiastole	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	ML	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-36
%STENOSIS Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
ValueType	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>CodeValue	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>CodingSchemeDesignator	(0008,0102)	SH	LN	ALWAYS	AUTO
>CodeMeaning	(0008,0104)	LO	RadiologyReport	ALWAYS	AUTO
ContinuityofContent	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
ContentTemplateSequence	(0040,A504)	SQ		ALWAYS	AUTO
>MappingResource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>TemplateIdentifier	(0040,DB00)	CS		ALWAYS	AUTO
ContentSequence	(0040,A730)	SQ		ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	HASCONCEPTMOD	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	CODE	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121049	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	LanguageofContentItemandDescendents	ALWAYS	AUTO
>ConceptCodeSequence	(0040,A168)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	en	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	English	ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	HASOBSCONTEXT	ALWAYS	AUTO

>ValueType	(0040,A040)	CS	CODE	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121005	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	ObservationType	ALWAYS	AUTO
>ConceptCodeSequence	(0040,A168)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121007	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	HASOBSCONTEXT	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121012	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	DeviceObserverUID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121070	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>ContinuityofContent	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>ContentSequence	(0040,A730)	SQ		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>ValueType	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02010003	ALWAYS	AUTO

>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	squaremeter	ALWAYS	AUTO
>>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	BPH	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	BPL	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	0217003	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	DmaxA:MaximumdiamterforCHA	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02170004	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	DminA:MinimumdiameterfoeCHA	ALWAYS	AUTO

>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02170005	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	DmaxB:MaximumdiameterforCHB	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02170006	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	DminB:MinimumdiameterforCHB	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02170007	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	AmaxA:MaximumareaforCHA	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	squaremillimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02170008	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	AminA:MinimumareaforCHA	ALWAYS	AUTO

>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	squaremillimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02170009	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBusn	ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	AmaxB:MaximumareaforCHB	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	squaremillimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	0217000A	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	AminB:MinimumareaforCHB	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	squaremillimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-37
CONTIEQUATION Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
ValueType	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>CodeValue	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>CodingSchemeDesignator	(0008,0102)	SH	LN	ALWAYS	AUTO
>CodeMeaning	(0008,0104)	LO	RadiologyReport	ALWAYS	AUTO
ContinuityofContent	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
ContentTemplateSequence	(0040,A504)	SQ		ALWAYS	AUTO
>MappingResource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>TemplateIdentifier	(0040,DB00)	CS		ALWAYS	AUTO
ContentSequence	(0040,A730)	SQ		ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	HASCONCEPTMOD	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	CODE	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121049	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO

>>CodeMeaning	(0008,0104)	LO	LanguageofContentItemand Descendents	ALWAYS	AUTO
>ConceptCodeSequence	(0040,A168)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	en	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	English	ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	HASOBSCONTEXT	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	CODE	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121005	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	ObservationType	ALWAYS	AUTO
>ConceptCodeSequence	(0040,A168)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121007	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	HASOBSCONTEXT	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121012	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	DeviceObserverUID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12. 100	ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121070	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>ContinuityofContent	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>ContentSequence	(0040,A730)	SQ		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>ValueType	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO

>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	squaremeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	BPH	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	BPL	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	021F0005	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	AreaA	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	squaremillimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO

>>RelationshipType	(0040,A010)	CS		ALWAYS	AUTO
>>ValueType	(0040,A040)	CS		ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>CodeValue	(0008,0100)	SH	021F0008	ALWAYS	AUTO
>>>CodingSchemeDesignator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>CodeMeaning	(0008,0104)	LO	AreaC	ALWAYS	AUTO
>>MeasuredValueSequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>MeasurementUnitsCodeSequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>CodeValue	(0008,0100)	SH		ALWAYS	AUTO
>>>>CodingSchemeDesignator	(0008,0102)	SH		ALWAYS	AUTO
>>>>CodeMeaning	(0008,0104)	LO	squaremillimeter	ALWAYS	AUTO
>>NumericValue	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-38
FlowVolumeTrace Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
ValueType	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>CodeValue	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>CodingSchemeDesignator	(0008,0102)	SH	LN	ALWAYS	AUTO
>CodeMeaning	(0008,0104)	LO	RadiologyReport	ALWAYS	AUTO
ContinuityofContent	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
ContentTemplateSequence	(0040,A504)	SQ		ALWAYS	AUTO
>MappingResource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>TemplateIdentifier	(0040,DB00)	CS		ALWAYS	AUTO
ContentSequence	(0040,A730)	SQ		ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	HASCONCEPTMOD	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	CODE	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121049	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	LanguageofContentItemand Descendents	ALWAYS	AUTO
>ConceptCodeSequence	(0040,A168)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	en	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	English	ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	HASOBSCONTEXT	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	CODE	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121005	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	ObservationType	ALWAYS	AUTO
>ConceptCodeSequence	(0040,A168)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121007	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	HASOBSCONTEXT	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121012	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	DeviceObserverUID	ALWAYS	AUTO

>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12. 100	ALWAYS	AUTO
>RelationshipType	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>ValueType	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>CodeValue	(0008,0100)	SH	121070	ALWAYS	AUTO
>>CodingSchemeDesignator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>CodeMeaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>ContinuityofContent	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>ContentSequence	(0040,A730)	SQ		ALWAYS	AUTO
>>RelationshipType	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>ValueType	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>ConceptNameCodeSequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BPH	ALWAYS	AUTO

>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	021B0003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	TAVp A: Maximum velocity	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	021B0014	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	Vmax A: Peak Systole Velocity A	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	021B0004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	VTI A: Velocity time integral A	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	meter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	021B0005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Area A: Selected area A	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	square millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	021B000A	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	SV A: Stoke Volume A	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	ML	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	021B000B	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	CO A: Cardiac output A	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	L/min	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	021B000C	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	SI A: SV index A	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mL/m ²	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	021B000D	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	CIA	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO

Table 8.1-39
Flow Volume VTI Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO

>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	BPH	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO

>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	021B0003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	TAVp A: Maximum velocity	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	021B0014	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	Vmax A: Peak Systole Velocity A	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	021B0004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	VTI A: Velocity time integral A	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	021B0005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Area A: Selected area A	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square millimeter	ALWAYS	AUTO
>>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH	021B000A	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SV A: Stoke Volume A	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>>Code Meaning	(0008,0104)	LO	ML	ALWAYS	AUTO
>>>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>>>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>>>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>>>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>>Code Value	(0008,0100)	SH	021B000B	ALWAYS	AUTO
>>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>>Code Meaning	(0008,0104)	LO	CO A: Cardiac output A	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>>>Code Meaning	(0008,0104)	LO	L/min	ALWAYS	AUTO
>>>>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>>>>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>>>>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>>>>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>>>Code Value	(0008,0100)	SH	021B000C	ALWAYS	AUTO
>>>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>>>Code Meaning	(0008,0104)	LO	SI A: SV index A	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>>>Code Meaning	(0008,0104)	LO	mL/m ²	ALWAYS	AUTO
>>>>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>>>>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO

>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	021B000D	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	CIA	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO

Table 8.1-40
MITRAL VALVE Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO

>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02570003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	E Vel : E-wave velocity	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02570004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	A Vel : A-wave velocity	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02570012	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	E/A : Evel/Avel	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02570013	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	A/E : Avel/Evel	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO

>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02570014	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	DcT : Deceleration time	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millisecond	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02570007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	E Dur : E-wave duration	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millisecond	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02570008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	A Dur : A-wave duration	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millisecond	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02570006	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	IRT : Isovelocity relaxation time	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millisecond	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-41
MR Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0257000E	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	dt: Doppler MR jet, rate of LV pressure rise	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millisecond	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02570020	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	dP/dt: Doppler MR jet, rate of LV pressure rise	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg/s	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02570021	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	MR Vel: Doppler MR velocity	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02570022	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	MR PG	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-42
MV Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO

>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02330003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	CEAMP: Amplitude of the E wave	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02330004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	DEAMP: Amplitude of the DE wave	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02330005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	CAAMP: Amplitude of the A wave	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO

>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02330006	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	EPSS: Distance between point E and the interventricular septum	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02330007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	DESLP: Opening speed of the valve	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter/second	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02330008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	EFSLP: Closing speed of the valve	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter/second	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0233000A	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	CA/CE: Ration of the A and E waves	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO

Table 8.1-43
OB Bestsel Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO

Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12. 100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO

>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO

>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BPD: Bipartitely diameter	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210009	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WEEK	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001A	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001B	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HC : Head circumference	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001C	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>>Text Value	(0040,A160)	UT	Hadlock	ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0102)	SH	0221001D	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0104)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0040,A300)	LO	WEEK	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	CS		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	CS		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001E	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-44
OB COMPBELL Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO

>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BPH	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BPL	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210007	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BPD: Bipartitely diameter	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02210008	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	DS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02210009	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	WEEK	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001A	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001B	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	HC : Head circumference	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001C	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO

>>>Text Value	(0040,A160)	UT	Hadlock	ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0102)	SH	0221001D	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0104)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0040,A300)	LO	WEEK	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>Code Meaning	(00400104)	LO	Day	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001E	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

**Table 8.1-45
OB HEADLOCK 1 Measurement**

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO

>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12. 100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO

>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BPD: Bipartitely diameter	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO

>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210009	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WEEK	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001A	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001B	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HC : Head circumference	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001C	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>>Text Value	(0040,A160)	UT	Hadlock	ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0102)	SH	0221001D	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0104)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0040,A300)	LO	WEEK	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO

>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001E	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-46
OB HEADLOCK 2 Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO

>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210007	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BPD: Bipartitely diameter	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210008	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210009	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	WEEK	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO

>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001A	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001B	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HC : Head circumference	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001C	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>>Text Value	(0040,A160)	UT	Hadlock	ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0102)	SH	0221001D	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0104)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0040,A300)	LO	WEEK	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001E	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-47
OB HEADLOCK 3 Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO

>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BPD: Bipartitely diameter	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210009	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WEEK	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001A	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001B	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HC : Head circumference	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001C	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>>Text Value	(0040,A160)	UT	Hadlock	ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0102)	SH	0221001D	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0104)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0040,A300)	LO	WEEK	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH	0221001E	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-48
OB HEADLOCK 4 Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO

Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO

>>>Code Value	(0008,0100)	SH	02210007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BPD: Bipartitely diameter	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210009	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WEEK	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001A	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001B	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HC : Head circumference	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO

>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001C	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT	Hadlock	ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0102)	SH	0221001D	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0104)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0040,A300)	LO	WEEK	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001E	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-49
OB JUSM Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO

>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12. 100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO

>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BPD: Bipartitely diameter	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO

>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210009	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WEEK	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001A	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001B	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HC : Head circumference	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001C	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>>Text Value	(0040,A160)	UT	Hadlock	ALWAYS	AUTO
>>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0102)	SH	0221001D	ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0104)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0040,A300)	LO	WEEK	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001E	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-50
OB MERTZ 1 Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO

>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BPD: Bipartitely diameter	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210009	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WEEK	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001A	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001B	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	HC : Head circumference	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001C	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT	Hadlock	ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0102)	SH	0221001D	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0104)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0040,A300)	LO	WEEK	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001E	ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-51
OB MERTZ 2 Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO

>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	BPL	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02210007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	BPD: Bipartitely diameter	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02210008	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02210009	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	WEEK	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,A30A)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	0221001A	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO

>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001B	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HC : Head circumference	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001C	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>>Text Value	(0040,A160)	UT	Hadlock	ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0102)	SH	0221001D	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0104)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0040,A300)	LO	WEEK	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001E	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-52
OB OSAKA Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210007	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	BPD: Bipartitely diameter	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210008	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210009	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	WEEK	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001A	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO

>>>Code Value	(0008,0100)	SH	0221001B	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HC : Head circumference	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001C	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>>Text Value	(0040,A160)	UT	Hadlock	ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0102)	SH	0221001D	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0104)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0040,A300)	LO	WEEK	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001E	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-53
OB TOKYO Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO

>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO

>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BPD: Bipartitely diameter	ALWAYS	AUTO

>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>Text Value	(0040,A160)	UT		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02210009	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WEEK	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001A	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,A30A)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001B	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HC : Head circumference	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO

>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0221001C	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	AUTHOR	ALWAYS	AUTO
>>>Text Value	(0040,A160)	UT	Hadlock	ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0102)	SH	0221001D	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0104)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0040,A300)	LO	WEEK	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	Day	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH	0221001E	ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	SD	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-54
Pulmonary Vein Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO

>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO

>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025E0003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	S1 Vel: S1-wave flow velocity	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025E0004	ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	S2 Vel: S2-wave flow velocity	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025E0005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	D Vel: D-wave flow velocity	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025E000C	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	DcT: Deceleration time	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millisecond	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025E000E	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	PVAVel: PVA-wave flow velocity	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025E0007	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	ARDUR: Atrial inversion duration	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millisecond	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025E0008	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	S VTI: S-wave VTI	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	025E0009	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	D VTI: D-wave VTI	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	meter		
>>>Numeric Value	(0040,A30A)	DS			

Table 8.1-55
PROSTATE Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO

>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12. 100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO

>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02290003	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	W	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02290004	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02290005	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	D: Cephalocaudal diameter of the prostate on the midsagittal image	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	millimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02290009	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	V-WHD: The approximate mass based on the prostate transverse diameter, anteroposterior diameter, and cephalocaudal diameter	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	cubic centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0229000C	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO

>>>Code Meaning	(0008,0104)	LO	W-WHD: The approximate column based on the prostate transverse diameter, anteroposeterior diameter, and cephalocaudal diameter	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	G	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	0229000E	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	s.g:	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	g/cm3	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

Table 8.1-56
TR Measurement

Attribute Name	Tag	VR	Value	Presence of Value	Source
Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>Code Value	(0008,0100)	SH	11528-7	ALWAYS	AUTO
>Coding Scheme Designator	(0008,0102)	SH	LN	ALWAYS	AUTO
>Code Meaning	(0008,0104)	LO	Radiology Report	ALWAYS	AUTO
Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
Content Template Sequence	(0040,A504)	SQ		ALWAYS	AUTO
>Mapping Resource	(0008,0105)	CS	DCMR	ALWAYS	AUTO
>Template Identifier	(0040,DB00)	CS		ALWAYS	AUTO
Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS CONCEPT MOD	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121049	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Language of Content Item and Descendents	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	en	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	ISO639_1	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	English	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CODE	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121005	ALWAYS	AUTO

>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Observation Type	ALWAYS	AUTO
>Concept Code Sequence	(0040,A168)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121007	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	HAS OBS CONTEXT	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	UIDREF	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Device Observer UID	ALWAYS	AUTO
>UID	(0040,A124)	UI	1.2.392.200036.9116.6.12.100	ALWAYS	AUTO
>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>Value Type	(0040,A040)	CS	CONTAINER	ALWAYS	AUTO
>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	121070	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	DCM	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	Findings	ALWAYS	AUTO
>Continuity of Content	(0040,A050)	CS	SEPARATE	ALWAYS	AUTO
>Content Sequence	(0040,A730)	SQ		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS	CONTAINS	ALWAYS	AUTO
>>Value Type	(0040,A040)	CS	NUM	ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010001	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	HT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	centimeter	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010002	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	WT	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>>Code Meaning	(0008,0104)	LO	kilogram	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH	02010003	ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	BSA	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	square meter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02010004	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	BP H	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	02010005	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	BP L	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	025B0008	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	TR VTI: Tricuspid valve regulation VTI	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	meter	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	025B000A	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	TR VP: Tricuspid valve maximum velocity	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO

>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	meter/second	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	025B000B	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	TR MPG: Tricuspid valve regurgitation mean pressure gradient	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	025B000C	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	TR PPG: Tricuspid valve regurgitation maximum pressure gradient	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	025B0012	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	RAPres: RV systole pressure	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO
>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO
>>Relationship Type	(0040,A010)	CS		ALWAYS	AUTO
>>Value Type	(0040,A040)	CS		ALWAYS	AUTO
>>Concept Name Code Sequence	(0040,A043)	SQ		ALWAYS	AUTO
>>Code Value	(0008,0100)	SH	025B001F	ALWAYS	AUTO
>>Coding Scheme Designator	(0008,0102)	SH	TSBus	ALWAYS	AUTO
>>Code Meaning	(0008,0104)	LO	RVSP	ALWAYS	AUTO
>>Measured Value Sequence	(0040,A300)	SQ		ALWAYS	AUTO

>>>Measurement Units Code Sequence	(0040,08EA)	SQ		ALWAYS	AUTO
>>>Code Value	(0008,0100)	SH		ALWAYS	AUTO
>>>Coding Scheme Designator	(0008,0102)	SH		ALWAYS	AUTO
>>>Code Meaning	(0008,0104)	LO	mmHg	ALWAYS	AUTO
>>>Numeric Value	(0040,A30A)	DS		ALWAYS	AUTO

8.1.2 Usage of Attributes from received IOD's

No SOP Class specific fields are required.

8.1.3 Attribute Mapping

The relationships between attributes received via Modality Worklist, stored in acquired images and communicated via MPPS are summarized in Table 8.1-57.

**Table 8.1-57
ATTRIBUTE MAPPING BETWEEN MODALITY WORKLIST, IMAGE AND MPPS**

Modality Worklist	Image IOD	MPPS IOD
--	--	Scheduled Step Attribute Sequence
Study Instance UID	Study Instance UID	>Study Instance UID
Referenced Study Sequence	Referenced Study Sequence	>Referenced Study Sequence
Accession Number	Accession Number	>Accession Number
--	Request Attributes Sequence	--
Requested Procedure ID	>Requested Procedure ID	>Requested Procedure ID
Scheduled Procedure Step ID	>Scheduled Procedure Step ID	>Scheduled Procedure Step ID
Scheduled Procedure Step Description	>Scheduled Procedure Step Description	>Scheduled Procedure Step Description
Scheduled Protocol Code Sequence	>Scheduled Protocol Code Sequence	--
--	Performed Protocol Code Sequence	Performed Protocol Code Sequence
--	Study ID	Study ID
--	Performed Procedure Step ID	Performed Procedure Step ID
--	Performed Procedure Step Start Date	Performed Procedure Step Start Date
--	Performed Procedure Step Start Time	Performed Procedure Step Start Time
--	Performed Procedure Step Description	Performed Procedure Step Description
Requested Procedure Description		
Requested Procedure Code Sequence	Requested Procedure Code Sequence	Requested Procedure Code Sequence
--	Referenced Study Component Sequence	--
--	>Referenced SOP Class UID	SOP Class UID
--	>Referenced SOP Instance UID	SOP Instance UID
--	Protocol Name	Protocol Name
Patient Name	Patient Name	Patient Name
Patient's ID	Patient's ID	Patient's ID
Patient's Birth Date	Patient's Birth Date	Patient's Birth Date
Patient's Sex	Patient's Sex	Patient's Sex
Referring Physician's Name	Referring Physician's Name	--

8.1.4 Coerced/Modified Fields

Not applicable to this product.

8.2 DATA DICTIONARY OF PRIVATE ATTRIBUTES

Not applicable to this product.

8.3 CONTROLLED TERMINOLOGY AND TEMPLATES

Not applicable to this product.

8.4 GRayscale IMAGE CONSISTENCY

Not applicable to this product.

8.5 STANDARD EXTENDED/SPECIALIZED/PRIVATE SOP CLASSES

Not applicable to this product.

8.6 PRIVATE TRANSFER SYNTAXES

Not applicable to this product.